

Manual Book






Please contact us with following information:

- 1. Screen shot of your order page, including product picture, name and order ID number.
- 2. Problem details with pictures / short video if possbile.

Packing List



NOTE: Please unpack the fixture carefully to avoid tangling of the hanging wires.

Safety Rules

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF; EITHER THE FUSE IS REMOVED OR THE CIRCUIT BREAKER IS TURNED OFF. TURNING THE POWER OFF USING THE LIGHT SWITCH IS NOT SUFFICIENT TO PREVENT ELECTRICAL SHOCK.

NOTE: The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions or situations that may occur. It must be understood that common sense, caution, and care, are factors which cannot be built into any product. These factors must be supplied by the person(s) installing this unit.

READ & SAVE THESE INSTRUCTIONS

CAUTION: Before assembling the lighting fixture, refer to the section titled Wiring Connections. If you feel you do not have enough electrical wiring experience, either refer to a do-it—yourself wiring handbook or have your lighting fixture installed by a qualified, licensed electrician.

UNPACK THE PACKAGE

Check the contents to be sure everything is included Tools Needed: Slotted screwdriver, Adjustable wrench, Step ladder, Wire cutters, wiring supplies as required by electrical code.

INSTALLATION & OPERATION INSTRUCTIONS GENERAL

Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the appropriate fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock. All electrical connections must be in accordance with local and National Electrical Code (NEC) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

Remove the fixture and the mounting packages from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

Be sure to read these installation instructions and review the diagrams thoroughly before installation.

LED DRIVER AND LED STRIP INCLUDED


This fixture uses LED driver and LED bulb strips (included, not dimmable).

ON/OFF SWITCH ONLY

Please just use an ON/OFF switch for it. Any dimmer switches may cause damage of the LED driver and LED bulbs, and cause flicker of the bulbs.

1. Installation Preparation

Tools You Need



If mounting to a support structure, you will also need the optional tools.

2. Mounting and Wiring




Fig. 1




Fig. 2




Fig. 3




Fig. 4

1. Mount the Bracket

Take off screws from outlet box (A). Secure the mounting plate (B) onto the box with flat washers and screws (C) taken off (Fig. 1). Fix two additional screws (D) with washers onto the ceiling if needed (optional).

2. Connect the Wires

Step 1: Press the wire locker and adjust the hanging wire to get a proper height and style (Fig. 2 and page 6).

Step 2: Connect the fixture wires (E) to the house wires (G), bare copper/green/yellow and green wire to ground wire, white or green to neutral wire, black or brown to hot wire. Wrap the connectors with electrical tape (H) separately.

Step 3: Spread apart the wires so that the live wires are on one side of the outlet box and the neutral wires are on the other side (Fig. 3).

3. Fix the Canopy

Fix the canopy (I) onto the (B) with nut (J) provided (Fig. 4).

4. Adjust the Balance

Adjust the wire length by pressing the wire locker on the canopy to get the style needed (page 6).

Assembly Styles

Styles below are for reference only.

Buyers are encouraged to compose their own unique configuration on site.









Trouble Shooting

1. Missing / Broken Parts

 Make a list of the missing/broken parts according to the packing list, take photos for broken parts, then email us for free replacements.

2. Bulbs Do Not Light Up / Flicker / Noisy Operation

- Check your power and switch to make sure it's power on.
- Check the bulb to make sure it's installed correctly.
- Make sure it's connected to an ON/OFF wall switch, not a dimmer switch.

3. Could Not Assemble

- Take photos of the lamp, contact seller for technical support.

Clean And Care

To clean, wipe fixture with soft cloth. Spray from chemical cleaners can discolor the finish of fixture. Do not use scouring pads, powders, steel wool or abrasive paper to clean this fixture.

Ordering Parts

Keep this manual for future reference, and in case replacement parts are needed. Available parts can be ordered from place of purchase. Use exact wording from diagrams when ordering parts.