





Installation manual



BT-084



Serial number:




Nr.	EN	Nr.	EN
1	Control panel	8	Sensor
2	Waterfall	9	Large jet
3	Hand shower	10	Air bottom jet
4	Function switch	11	Medium jet
5	Thermostatic switch	12	LED underwater light
6	Pillow	13	Drainer
7	Air regulator	14	Suction




All measurements are given in Inches
 Designs and sizes can vary. We accept no liability for errors,
 manufacturing tolerance and product changes.


1




2




3





4







5




6






7




8



9



10




Technical parameters

Rated voltage	AC220-240V 60Hz
Rated current	11.8 A
Normal rated power	2.6KW
Dimension water pipes	1/2"
Dimension drainage pipe	40mm
Max temperature hot water	176°F
Recommended hot water	149°F
Operating pressure	Max 0,8mPa (8 bar)
Recommended operating pressure	0,1-0,5 mPa (1-5 bar)



EN12764:2004+A1

Flowchart



1	Air regulator	8	Cold water supply
2	Thermostatic switch	9	Waterfall
3	Flow control switch	10	Jet
4	Function switch	11	Air pump
5	Hand shower	12	Water pump
6	Air bottom jet	13	Suction
7	Hot water supply		

Electrical wiring diagram

