

ASSEMBLY INSTRUCTIONS


ASSEMBLY
REQUIREMENTS

2-Person
Assembly

Assembly Time
(Approximate) 30 MINUTES

Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product. Contact our customer service department in case there are any missing or damage parts or hardware. Replacement parts are normally shipped within 2 or 3 days.



ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List, and ensure parts and hardware are correct before assembly.
Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent scratch and damage to parts.

SAFETY PRECAUTION

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY

1. Allow ample room for assembly **and assemble the product near where the product will be placed.**
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all of the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat, level surface.
7. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

CARE AND MAINTENANCE

- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or delaminate.
- Do not place hot items (e.g. hot drinks) directly onto the wood surface.
- Do not drag and/or pull the furniture.






This product is for indoor and household use only - not for commercial use.

ASSEMBLY INSTRUCTIONS

PART LIST (FOR 1 TABLE)


NO.	COMPONENT	QTY.
P1	TABLE TOP WITH APRON	1 PC.
P2	TABLE LEG	4 PCS.

HARDWARE LIST (FOR 1 TABLE)

NO.	DESCRIPTION	QTY.	EXTRA
H1	HEX BOLT 5/16" x 2-1/2" 	8 PCS.	1 PC.
H2	SPRING WASHER 5/16" 	8 PCS.	1 PC.
H3	FLAT WASHER 5/16" 	8 PCS.	1 PC.
H4	WRENCH 	1 PC.	-
	NAIL HEAD 		1 PC.

** EXTRA HARDWARE FOR SPARE USE.

STEP 1



- a) With assistance, lay Table Top (P1) flat on a material that does not damage the part with the bottom-side facing up.
- b) Position Table Leg (P2) against the corner of the table aprons and align the screw holes on (P2) to the screw holes on the corner block of the apron.
- c) Insert Hex Bolt (H1) fitted with Spring Washer (H2) and Flat Washer (H3) through each hole on the corner block into the screw hole on (P2). Use Wrench (H4) to drive (H1) to fasten Table Leg (P2) to corner block. Do not tighten (H1) completely until both bolts are in place - do not overtighten.
- d) Repeat the above assembly procedure for the other three legs.
- e) With assistance, set the table right-side up when all 4 legs are installed.