
ASSEMBLY INSTRUCTION

ITEM : N759P475785/N759P475786


Storage Cabinet














⚠ WARNING !	
	This product is NOT a Clothing Storage Unit (CSU) DO NOT use it for clothing storage. Improper use may cause furniture tipover.

ASSEMBLY INSTRUCTION










ITEM : N759P475785/N759P475786



PART LIST (N759P475785)

(A) x 1  Top Panel	(N) x 1  Bottom Panel
(H) x 1  Drawer Front Panel	(R1) x 2  Left Side Panel of Door Shelf
(I1) x 1  Drawer Left Side Panel	(R2) x 2  Right Side Panel of Door Shelf
(I2) x 1  Drawer Right Side Panel	(S) x 2  Upper Shelf of Door Shelf
(J) x 1  Drawer Back Panel	(T) x 4  Bottom Shelf of Door Shelf
(K) x 1  Drawer Bottom Panel	(U) x 6  Bar of Door Shelf
(L) x 1  Middle Panel	

PART LIST (N759P475786/Hardware in this SKU)

(B1) x 1 Upper Left Side Board 	(G2) x 1 Upper Right Door 
(B2) x 1 Upper Right Side Board 	(M1) x 1 Bottom Left Side Panel 
(C) x 1 Front Fix Shelf 	(M2) x 1 Bottom Right Side Panel 
(D) x 1 Upper Fix Shelf 	(O) x 2 Bottom Fix Shelf 
(F) x 1 Adjustable Shelf 	(P) x 2 Bottom Back Panel 
(E) x 2 Upper Back Panel 	(Q1) x 1 Bottom Left Door 
(G1) x 1 Upper Left Door 	(Q2) x 1 Bottom Right Door 