


# Assembly Instructions

**Caution :** You must read this before you proceed.

## CHAIR



**CAUTION:** This chair is NOT a TOY.  
Keep your child/children at bay during the assembly process.

### Parts List


No.	Picture	Description	Qty
A		Backrest Panel	2
B		Chair Seat Panel	2
C		Outer Right Legs with Pre-attached Levellers	1
D		Outer Left Legs with Pre-attached Levellers	1
E		Inner Right Legs with Pre-attached Levellers	1
F		Inner Left Legs with Pre-attached Levellers	1
G		Middle Table	2

# Hardware

No.	Picture	Description	Qty
①		Washer (8mm)	25
		Springs Washer (8mm)	25
		Nut (8mm)	25
②		Rubber Ring	9
③		Studs (8*30mm)	9
④		Spanner	1
⑤		Screwdriver	1

# Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


# Assembly Steps

## Overview




This CHAIR has multiple parts and may require up to some 60 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions here below to familiarise the parts and steps before assembly.

## Step 1




Place all parts on a clean, soft surface.

## Step 2




Fix the two Studs(③) onto the Inner Left Legs (F) with the Screwdriver(⑤). Then put the Rubber Ring (②) on the screws on the Inner Left Legs (F). Then attach the Two Middle Tables(G) with Inner Left Legs(F) using Washers, Spring Washers and Nuts(①) with Spanner (④). DO NOT OVERTIGHTEN, yet.

### Step 3




Repeat Step 2, Fix the two Studs(③) onto the Inner Right Legs(E) with the Screwdriver(⑤),put the Rubber Ring(②) on the screws on the Inner Right Legs (E). then attaching the Inner right Legs (E) with the 2 Middle Tables (G) using Washers, Spring Washers and Nuts (①) with Spanner (④). DO NOT OVERTIGHTEN, yet.

### Step 4




Then place Seat Panel (B) into the pre-attached bolts of the Outer Left Legs(D) using Washers, Spring Washers and Nuts(①) with Spanner(④). DO NOT OVERTIGHTEN, yet.

### Step 5




Place the Backrest Panel(A) into the pre-attached bolts of the Outer Left Legs(D) using Washers, Spring Washers and Nuts(①) with Spanner(④). DO NOT OVERTIGHTEN, yet.

## Step 6




Repeat Step 4 & Step 5, attaching the Backrest Panel (A) and Seat Panel (B) with the Outer Right Legs (C) using Washers, Spring Washers and Nuts (1) with Spanner (4).  
DO NOT OVERTIGHTEN, yet.

## Step 7




Now attach the pre-assembled Outer Left Legs (D) with the pre-assembled Inner Left Legs (F) where the Backrest Panel (A) and Seat Panel (B) meet the Inner Left Legs (F) using Washers, Spring Washers and Nuts (1) with Spanner (4).  
DO NOT OVERTIGHTEN, yet.

## Step 8



Then attach the pre-assembled Outer Right Legs (C) with the pre-assembled Inner Right Legs (E) where the Backrest Panel (A) and Seat Panel (B) meet the Inner Right Legs (E) using Washers, Spring Washers and Nuts (1) with Spanner (4).  
DO NOT OVERTIGHTEN, yet.

## Step 9



Stand the Tete Chair rightside up.



















Now, fully and securely, tighten all nuts, at all joints.

Adjust the Pre-attached levellers at the bottom of the chair legs until the unit is level with the ground.

Your chair is ready for use.

Caution: This chair can only be used on a flat, level surface.

## Care & Maintenance

-   ● Do not put hot items directly on furniture surface
  -   ● Do not clean furniture with harsh cleansers or polish.
  -   ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
  -   ● Children should not climb or jump on the furniture.
  -   ● Do not write on furniture without a padded barrier to protect the surface.
  -   ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
  -   ● Not for commercial use. For residential use only .
  -   ● Stains may be removed with mild soap solution and damp cloth.
- 
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .

### What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, table ware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and electric cords, and furniture.

### Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

### Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

### Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

