

ASSEMBLY INSTRUCTIONS

DINING TABLE





IMPORTTANT NOTE:


- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CAPET TO AVOID THE PARTS FORM BEING SCARTCHED .
- 2 BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTILL THE TABLE FULLY SET-UP



| Part List For One | | | Hardware List For One | | | |
|-------------------|----------------------|------|-----------------------|----------------------|---------------------------------|-------|
| No. | Hardware Description | Q'ty | No. | Hardware Description | | Q'ty |
| А | Table top | 1pc | 1 | | Bolt Ø1/4" x 40mm | 8pcs |
| | | | 2 | | Bolt Ø1/4" x 50mm | 2pcs |
| В | Table Leaf | 1pc | 3 | 0 | Lock washer Ø1/4" x11x1.5mm | 10pcs |
| | | ' | 4 | | Flat washer Ø1/4" x16 x1.5mm | 10pcs |
| С | Side Support | 2pcs | 5 | | Allen key 4 x 60 mm | 1pc |
| | | | | | | |
| D | Botom Support | 1pc | | | | |
| | | | | | | |









ASSEMBLY INSTRUCTIONS

DINING CHAIR



IMPORTTANT NOTE:


- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CAPET TO AVOID THE PARTS FORM BEING SCARTCHED .
- 2 BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTILL THE CHAIR FULLY SET-UP




| Part List For One | | | | Hardware List For One | | | |
|-------------------|----------------------|--------------|------|-----------------------|----------------------|--------------------------------|-------|
| No. | Hardware Description | | Q'ty | No. | Hardware Description | | Q'ty |
| А | Backrest | | 1pc | 1 | | Bolt Ø1/4" x 70mm | 4pcs |
| | | | | 2 | | Bolt Ø1/4" x 50mm | 4pcs |
| В | | Seat frame | 1pc | 3 | | Bolt Ø1/4" x 40mm | 2pcs |
| | | Franklass | 1.55 | 4 | 0 | Lock washer Ø1/4" x11x1.5mm | 10pcs |
| С | | Front leg | 1pc | | | Flat washer | 10 |
| D | \Longrightarrow | Front leg | 1pc | 5 | | Ø1/4" x16 x1.5mm | 10pcs |
| E | | Side Support | 1pc | 6 | | Allen key 4 x 60 mm | 1pc |
| F | | Side Support | 1pc | 7 | ₹₹₹₹ | Screw #4 x 38 mm | 4pcs |


ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)


Step 1



Step 2









ASSEMBLY INSTRUCTIONS

DINING CHAIR



IMPORTTANT NOTE:


- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CAPET TO AVOID THE PARTS FORM BEING SCARTCHED .
- 2 BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTILL THE CHAIR FULLY SET-UP



| Part List For One | | | | Hardware List For One | | | |
|-------------------|----------------------|--------------|------|-----------------------|----------------------|--------------------------------|-------|
| No. | Hardware Description | | Q'ty | No. | Hardware Description | | Q'ty |
| А | Backrest | | 1pc | 1 | | Bolt Ø1/4" x 70mm | 4pcs |
| | | | | 2 | | Bolt Ø1/4" x 50mm | 4pcs |
| В | | Seat frame | 1pc | 3 | | Bolt Ø1/4" x 40mm | 2pcs |
| | | Franklass | 1.55 | 4 | 0 | Lock washer Ø1/4" x11x1.5mm | 10pcs |
| С | | Front leg | 1pc | | | Flat washer | 10 |
| D | \Longrightarrow | Front leg | 1pc | 5 | | Ø1/4" x16 x1.5mm | 10pcs |
| E | | Side Support | 1pc | 6 | | Allen key 4 x 60 mm | 1pc |
| F | | Side Support | 1pc | 7 | ₹₹₹₹ | Screw #4 x 38 mm | 4pcs |

ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)

Step 1



Step 2

