


Thank you for your purchase!



Bookshelf with Sliding Door

ASSEMBLY INSTRUCTIONS

Before You Begin: Phillips screwdriver required for assembly (Not Included).

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-




Use the anti-tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Please note that only the standard anti-tip hardware is provided. You will need to provide wall plugs and screws applicable for your wall type.

Components

Please check you have all the parts listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more hardware may be supplied than is required.

A  Wood Dowel x 28	B  Male Camlock x 26	C  Female Camlock x 26
D  Ø20 Sticker x 26	E  Allen Wrench M4 x 1	F  6.8*48mm Screw x 8
G  6*12mm Screw x 14	H  Connector x 7	I  Pulley Guard Rail x 1
J  Plastic Wedge x 16	K  3*17mm Screw x 16	L  Shelf Support Pin x 16
M  Pulley x 2	N  Plate x 2	O  Anti-Tip Hardware Pack x 2
P  4*12mm Screw x 4	Q  4*18mm Screw x 2	R  Handle x 1
S  4*20mm Screw x 8	T  6*35mm Screw x 4	U  Bolt x 4




Tools required



Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170




The screw length is measured from the head to the point (30mm screw shown).

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note: Ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4


Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.




Assembly Instructions




Assembly Instructions

Step 1




Step 2




Assembly Instructions

Step 3




Step 4




Assembly Instructions

Step 5




Step 6




Assembly Instructions

Step 7





Step 8





Assembly Instructions

Step 9




Step 10




Assembly Instructions

Step 11




Step 12




Assembly Instructions

Step 13




Step 14




Assembly Instructions

Step 15




Step 16




Assembly Instructions

Step 17







Step 18






Assembly Instructions

Step 18.1






Assembly Instructions

Step 19




Step 20




Assembly Instructions

Step 21




Step 22




Assembly Instructions

Step 23




Step 24



Assembly Instructions

Step 25



Step 26

The unit is floor standing, but it is recommended that the unit is secured to the wall.


1. Move the unit into desired position.
2. Mark the wall with a suitable scribe the position of the fixing holes.



Warning:
Before drilling, check wall for hidden pipes and cables.

3. Drill holes and insert 2 x wall plug
4. Attach 2 x Wall Straps to to the top of the unit using 2 x Washers and 2 x Screws
5. Secure the straps to the wall using 2 x Washers and 2 x Screws

Note: To hide the straps behind the unit, drill the holes lower than the top of the unit




Assembly Instructions

Step 27


The unit is floor standing, but it is recommended that the unit is secured to the wall.

1. Move the unit into desired position.
 2. Mark the wall with a suitable scribe the position of the fixing holes.
-  **Warning:** Before drilling, check wall for hidden pipes and cables.
3. Drill holes and insert 2 x wall plug
 4. Attach 2 x Wall Straps to the top of the unit using 2 x Washers and 2 x Screws
 5. Secure the straps to the wall using 2 x Washers and 2 x Screws

Note: To hide the straps behind the unit, drill the holes lower than the top of the unit



Step 28



Assembly is complete.

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit**. **Consult a qualified tradesperson if you are unsure.**


Hints:

- 1: General rule:  always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 "Shield Anchor" wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.

Quality and Safety Guidelines

- Please follow the static and dynamic weight capacity limits provided on this item. If you are unsure of the weight capacities for this product, email us
- Please use this item on a stable, level surface only. All storage unit legs should contact the flooring surface when in use. Do not use this item if any instability is detected.
- Please install and use anti-tipping devices.
- For maintenance instructions and replacement parts, please email us
- This item is intended as a shelving unit only, do not climb, stand or sit on this item.
- Do not use this item as a TV stand.
- Do not use as a clothing storage unit.
- The item is intended to be used indoors.
- For product longevity, product safety and product integrity, protect from wet or humid weather and store indoors in a dry location.