




Installation Manual







① X2pc



② X1pc



③ X1pc




④ X1pc

M8X25




Ⓐ X4pc

M6X35



Ⓑ X2pc

M6X30




Ⓒ X4pc




Ⓓ X6pc

M6







Ⓔ X1pc



M8







Ⓕ X1pc



1

 	 ©X2pc	 ⓓX2pc
---	---	--









2

 	 ©X2pc	 ⓓX2pc
---	---	--



3

 	 Ⓐ X4pc	 Ⓑ X2pc	 Ⓓ X2pc
---	---	---	---





Tighten all screws to 100% after inspection.

