


## TROUBLE SHOOTING

If you've followed the instructions carefully and your faucet still does not work properly, take these corrective steps.

| Problem                             | Cause                                                             | Action                                                                                                                             |
|-------------------------------------|-------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| Low flow                            | Aerator(4) or fliter(8) may be clogged                            | Unscrew aerator to check rubber packing or replace aerator.<br><b>(Note: some models require wrench to remove aerator.)</b>        |
| Faucet leaks from under handle      | Bonnet(2) nut has come loose or cartridge(3) needs to be reseated | Remove handle and cap. Using a wrench, ensure bonnet nut is tight.                                                                 |
| Water will not shut off completely. | Dirty or worn out plastic washer in the cartridge.                | Adjust or replace cartridge.<br><b>WARNING: Failure to securely tighten bonnet nut with a wrench could result in water damage.</b> |

## CLEAN AERATOR AND FLITER



## CLEANING AND CARE

Clean the faucet often with a soft cloth to keep it looking like new. For heavy cleaning you can use mild liquid detergents or non-abrasive liquid polisher. Rinse with water and dry with a soft cloth. Avoid abrasive cleaners, steel wool and harsh chemicals as these will dull the finish and void your warranty.

LIMITED LIFETIME WARRANTY

KIBI provides its customers with an extensive warranty as a result of our excellent workmanship and high quality components used in our products.

Mechanical warranty: A limited lifetime warranty is provided on all mechanical parts to be free from manufacturing defects in materials and workmanship under normal use for as long as the original purchaser owns their home.


Finish warranty: A 5-year warranty is provided on all KIBI faucet finishes to the original purchaser against manufacturing defects in materials and workmanship.

At its sole discretion, KIBI will repair or replace any part or finish that proves to be defective in material and/or workmanship under normal installation, use and service.

This warranty is extended to the original consumer owner, but does not cover installation or any other labor charges. In no event shall KIBI be liable for any incidental, consequential or special damages, installation cost, labor, travel time, freight costs incurred, lost profits, or contingent liabilities. KIBI makes no representation that its products comply with any or all local building or plumbing codes. It is the consumer's responsibility to determine local code compliance.




## Installation Guide




Circular x  
KBF1010

## DIMENSIONS

Circular X- KBF1010



## PARTS



| Circular X- KBF1010 |                    |
|---------------------|--------------------|
| 1                   | Lever Handle       |
| 2                   | Bonnet nut and cap |
| 3                   | Cartridge          |
| 4                   | Aerator            |
| 5                   | Trim Ring          |
| 6                   | Mounting Bracket   |
| 7                   | Waterlines         |
| 8                   | Fliter             |

## INSTALLATION

