



# PREPARATION

Before beginning the assembly of the product, make sure all parts are present. Compare the parts with the package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble the product. Tool required for assembly (included): Allen Key and Wrench.



Step 1: Put the leg (C) to the leg (B) same as picture . Use the wrench (D2) to tight.



Step 2: attach the legs to the table top (A) as shown on the picture. Use the Allen bolt (D1) and tighten by using the Allen key (D3) and wrench (D2).

## CARE AND MAINTENANCE







Store outdoor furniture indoors or cover well when it is not in use. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

## NOTICE

Please make sure that you have all parts indicated before you begin assembly of this item.

Product Dimension: 27.56"W x 27.56"D x 14.17"H

### Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
<b>A</b>	Table top		<b>1x</b>
<b>B</b>	Outside leg		<b>1x</b>
<b>C</b>	Inside leg		<b>1x</b>
<b>D1</b>	Allen bolt	 M6x50	<b>4x</b>
<b>D2</b>	Wrench		<b>1x</b>
<b>D3</b>	Allen Key		<b>1x</b>

Weight capacity : 40 lbs.

Warning : Do not stand on the table

Warning : Do not torque bolts / screws

