



ASSEMBLY INSTRUCTIONS


DINING TABLE




Tools Required (Not Included)



Rubber Hammer




Phillips Screwdriver



Wrench






Cordless Drive (*)



(*) NOTE: Optional - use in place of hex drive.

Identifying the Hardware-Identify the hardware using the illustrations below.



01

