

WARNING !!

Children have died from furniture tip over . Tip restraints have been included with this product, you must install the tip restraints according to these instructions in order to minimize the risk of furniture tipping.

NEVER allow children to climb or hang on furniture, including drawers or cabinet doors.

In addition to installing the restrains, to help prevent tip-over

- 1. For use with televisions weighing X lbs or fewer. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury. NEVER use with CRT televisions.
- 2. Do not stand on the product



**WARNING**

Children have died from furniture tipover. To reduce the risk of furniture tipover :



- ALWAYS install tipover restraint provied.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers
- Do not defeat or remove the drawer interlock system.

*This is a permanent label.
Do not remove!*

Assembly Instructions


CAUTION: You must read this before you proceed.

Care & Maintenance

-  ● Not for commercial use. For residential use only.
 -  ● Furniture may scratch floors. We recommend using furniture pads to protect your floors.
 -  ● Do not put hot items directly on furniture surface.
 -  ● Do not clean furniture with harsh cleansers or polish.
 -  ● Do not place furniture under direct sunlight.
 -  ● Do not place furniture near heating or cooling vents.
 -  ● Do not write on furniture without a padded barrier to protect the surface.
 -  ● Do not place furniture outside . For indoor use only.
 -  ● Stains may be removed with mild soap solution and damp cloth.
 -  ● Children should not climb or jump on the furniture.
-
-  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in the back panel for hardware packs.

BOOKCASE




















CAUTION : This Bookcase is NOT a TOY.

Keep your child/ children at bay during the assembly process.

Whenever moving/lifting the Bookcase and prevent damage to the bookcase, two adults are needed to execute these actions


Part List


Label	Picture	Description	QTY
A		Shelf Panel	5
B		Front Bar	2
C		Back Panel	2
D		Support Bar	10
E		Bracing Bar	10

<u>Hardware</u>			
Label	Picture	Description	QTY
①		Bolt (M6*40mm)	21
②		Bolt (M6*35mm)	21
③		Bolt (M6*30mm)	21
④		Sleeve Nuts (6x15mm)	21
⑤		Screw (M6*45mm)	7
⑥		Allen Wrench	2
<u>Bookcase Restraint Device Hardware:</u>			
⑦		Screw (M4*50mm)	3
⑧		Screw (M4*15mm)	7
⑨		Plastic Wall Plug	3
⑩		L Bracket	2
⑪		Screwdriver (Not Provided)	1
⑫		Hammer (Not Provided)	1
⑬		Electric Drill (Not Provided)	1
⑭		Washer	3

Assembly Preparation


Before Beginning Assembly:



-  • Read instruction, cover to cover-
-  • Have 2 adults on hand for assembly-
-  • Do not assembly on flooring or carpet-
-  • Assemble on a clean non- marring surface (packing foam)-
-  • Save all packaging until finished-


Assembly Step

Overview




This Bookcase has multiple parts and may require up to 45 minutes to assemble. To give you an overview of the Bookcase parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarize yourself with the parts and steps before assembly.

Step 1:




Unpack and place all parts on a clean, non-marring surface.

Step 2:




Attach the Shelf Panel (A) to Front Bar (B) using Bolts③and Allen Wrench⑥ as shown above picture.
Do not fully tighten the Bolts.

Step 3.1:




Attach the Support Bar (D) to Bracing Bar (E) using the Bolts① and Sleeve Nut④ with AllenWrench⑥ as shown above picture.
Do not fully tighten the Bolts.

Step 3.2:



Attach the [Support Bar (D) + Bracing Bar (E)] assembly to Shelf Panel (A) using the Bolts② with Allen Wrench⑥ as shown above picture.
Do not fully tighten the Bolts.


Step 4:




Position Back Panel (C) as above picture then attach the Back Panel (C) to Support Bar (D) using Bolt ③ and Allen Wrench⑥.

Do not fully tighten the Bolts.

Step 5:



Continue to secure Back Panel (C) to Shelf Panel (A) using Screws ⑤ and Allen Wrench ⑥ as shown above picture.



Turn the Bookcase right side up.

Place the Bookcase on a **LEVEL SURFACE**.

Inspect it and make sure all parts are adequately connected.

Don't push too hard, shake on the bed.

This would help to align all the parts at all the joint areas.

CAUTION 1: When tightening these screws, tighten sequentially.

DO NOT tighten any screw fully and then towards the next one.

This would cause the frame to warp.

If there is still wobbles, loosen the screws and execute this same process.

DO NOT tighten any screw fully and then towards the next one.

WARNING!! IF BOOKCASE IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Ensure all screws are fully locked into position.


The bookcase is ready to be used.

CAUTION 2: This bookcase can only be used on a flat, level surface.

Bookcase Restraint Device Installation Instructions:




Serious or fatal crushing injuries can occur from tipping furniture.
To help prevent tip-over: **ALWAYS** secure this furniture to the wall using Bookcase Restraint Device.
See product instructions for more ways to help prevent furniture tip-over.





To secure Bookcase against the wall, attach 2pcs Metal Brackets ⑩ to the wall and on the Bookcase. Then use Bookcase Plastic Wall Plug ⑨ to connect the Metal Brackets ⑩ on the wall and the Bookcase.

Step 6:





Turn the Bookcase outwards, as shown above.
Then fix the L-shaped Metal Brackets (10) to the back of the Bookcase with
Screws (8) and Screwdriver (11)

Step 7.1:




Locate the two positions marked on the main wall panel. These precise drilling points, which represent where the plastic wall plugs and screws will be installed later, are highlighted within circles. Using electric hand drill ⑬ (as shown in the magnified detail box), drill into each of these marked spots. It is important to ensure the correct drill bit size is used for the wall plugs, creating holes that are clean and perpendicular to the wall surface to ensure a secure installation.

Step 7.2:



Use a hammer ⑫ to gently tap the 2 Plastic Wall Plugs ⑨ into the pre-drilled holes until they are flush with the wall surface.



Find the location of the screw holes on the wall.

You can mark these points in two ways as below:

1) Move the Bookcase back to the wall. Mark two points the same height as the Bookcase on the wall.

Note: The Metal Brackets need to be secured to solid, load bearing surface. Please use a Stud Finder(not supplied) if needed to locate the Wall Frame.

2) Measure the height from the floor to the Metal Brackets (10) on the Bookcase with ruler/measuring tape and mark on the wall to keep them accurate and same height.

(Caution: The Bookcase Plastic Wall Plug(9)between the product and Metal brackets(10)on the wall should be within 3.5")

Then attach L-shaped Metal Brackets (10)to wall using Screws(7)and Washer(14) with. Screwdriver(11)

The Bookcase Restraint Device is installed and your Bookcase is ready for use.