

ASSEMBLY & INSTALLATION

INSTRUCTIONS FOR WALL LAMP

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.


ASSEMBLY AND INSTALLATION

1. At the center of the BRACKET(2) there are two perforated slots. Knock out the set matches your OUTLET BOX(1)
2. Secure the BRACKET(2) to the OUTLET BOX (1) with MOUNTING SCREWS (3).
3. Attach the BLACK SUPPLY WIRE (8) to the SMOOTH (or BLACK) FIXTURE LEAD WIRE (9) by using the WIRE CONNECTOR (10). At the same manner, attach the WHITE SUPPLY WIRE (6) to the RIBBED (or WHITE) FIXTURE LEAD WIRE (7). Loop the FIXTURE GROUND WIRE (4) around the GROUND SCREW (11) of the BRACKET(2). (Note: Be sure to provide an extra 3" length of the FIXTURE GROUND WIRE (4) for connection to the SUPPLY GROUND WIRE (5).) Tighten the GROUND SCREW (11). Connect the remaining FIXTURE GROUND WIRE (4) to the SUPPLY GROUND WIRE (5) using a WIRE CONNECTOR (10). Place wiring and connections inside the OUTLET BOX (1).
4. Place the COVER PLATE (12) onto the FIXTURE MOUNTING SCREWS (2), and secure it into place using the DECORATIVE NUTS(13)provided.

ASSEMBLY AND INSTALLATION (Continued)

6. Slide the GLASS SHADE(15) over the SOCKET(14), secure with the SOCKET RING(16) by using SOCKET RING TOOL(17) provided.
7. Screw light bulbs into the sockets and make sure they do not exceed the maximum wattage specified on the fixture's wattage rating label, **MAXIMUM 100W.**
8. The lamp body exclude light bulbs

INSTALLATION IS NOW COMPLETED



- | | |
|--|----------------------|
| 1. OUTLET BOX | 10. WIRE CONNECTOR |
| 2. BRACKET | 11. GROUND SCREW |
| 3. MOUNTING SCREW | 12. COVER PLATE |
| 4. FIXTURE GROUND WIRE | 13. DECORATIVE NUT |
| 5. SUPPLY GROUND WIRE | 14. SOCKET |
| 6. WHITE SUPPLY WIRE | 15. GLASS SHADE |
| 7. RIBBED (OR WHITE) FIXTURE LEAD WIRE | 16. SOCKET RING |
| 8. BLACK SUPPLY WIRE | 17. SOCKET RING TOOL |
| 9. SMOOTH (OR BLACK) FIXTURE LEAD WIRE | |