





ASSEMBLING INSTRUCTIONS






Accent Chair





Legs and hardware are stored in the bottom of the seat, please take them out for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


PART	DRAWING	DESCRIPTION	QTY
A		Chair Back	1 PC
B		Chair Seat	1 PC
C		Seat Cushion	1 PC
D		Metal Leg 3-5/32"x3-5/32"x7-1/2"	4 PCS

PART	DRAWING	DESCRIPTION	QTY
1		Bolt Ø5/16"×1-1/2"	6 PCS
2		Bolt Ø5/16"×1"	8 PCS
3		Spring Washer Ø5/16"	14 PCS
4		Flat Washer Ø5/16"×3/4"	14 PCS
5		Allen Key M4	1 PC

STEP 1:



x6




x8



x14



x14





x1

ASSEMBLING INSTRUCTIONS

Accent Chair


STEP 2:




ASSEMBLING INSTRUCTIONS

Accent Chair

STEP 3:




COMPLETED



Care Instruction for Chenille Furniture:

In order to maintain the original appearance of your chenille furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage chenille.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connection are tight, Re-tighten if necessary

 For item use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.