





ASSEMBLY INSTRUCTIONS

WF306077/078/083


SINGLE SOFA



SINGLE SOFA is packed in 3 cases


Carton	Disignation	Part	Hardware/Leg
1/3 WF306077	Backrest	#1 	
2/3 WF306078	Seat	#2 	#A #B #C #D #E #F #G #H #I
3/3 WF306083	Left arm	#3 	
	Right arm	#4 	

ASSEMBLY INSTRUCTIONS




PARTS

#1 1pc




BACKREST

#2 2pcs




BACKREST

#3 1pc



LEFT ARM


#4 1pc



RIGHT ARM

HARDWARE/LEG

#A 4 pcs



LEG

#B 8 pcs



WHOLE TOOTH SCREW
90mm L

#C 8 pcs




NUT

#D 8 pcs



FLAT WASHER
22mm

#E 1 pc



WRENCH

#F 8 pcs



BOLT 25MM L

#G 8 pcs



SPRING WASHER

#H 8 pcs



FLAT WASHER
16mm


#I 1 pc




ALLEN KEY

ASSEMBLY INSTRUCTIONS

STEP1:




STEP2:



ASSEMBLY INSTRUCTIONS

STEP3:



STEP4:

