



# Assembly Instructions

**Caution :You must read this before you proceed**


## ARMLESS SOFA



### Parts List


| Label | Picture                                                                             | Description  | QTY |
|-------|-------------------------------------------------------------------------------------|--------------|-----|
| A     |  | Seat Frame   | 1   |
| B     |  | Backrest     | 1   |
| C     |  | Back Cushion | 1   |
| D     |  | Leg          | 4   |

## Hardware

| Label | Picture                                                                           | Description      | QTY |
|-------|-----------------------------------------------------------------------------------|------------------|-----|
| ①     |  | Washer Ring      | 7   |
| ②     |  | Allen key        | 1   |
| ③     |  | Bolt M8*20mm     | 2   |
| ④     |  | Spring Washer    | 2   |
| ⑤     |  | Flat Washer      | 2   |
| ⑥     |  | Connecting Piece | 1   |

## Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

# Assembly Steps

## OVERVIEW





This ARMLESS SOFA has multiple parts and may require up to some 30 minutes to assemble.

To give you an overview of the ARMLESS SOFA parts, the above picture is to help you put the various parts into perspective.

Please read through the instructions below to familiarise yourself with the parts and steps before assembly.


## Step 1



Position the Seat Frame (A) on its back, as shown.

Unzip to open pouch and remove the 4 wooden legs, Back Cushion (C) and hardware, close the pouch.

## Step 2



Install the Legs(D) into the bottom of the Seat Frame (A) by placing a Washer Rings(①) onto the threaded stem of the Legs.

And then insert the threaded stem into the threaded mounting position at each Corner of the Bottom Seat Frame (A)).

Tighten by turning the Legs clockwise.


Note: The use of Washer Rings(①) are OPTIONAL and are especially useful to help alleviate slight wobbles.

Some Legs may need more than one Washer Ring whilst some Legs may not need any.

Position Sofa right side up and test for stability on a Level Surface.


Add or remove Washer Rings(①) where needed to achieve stability.

### Step 3




Cover the bottom of the Seat Frame (A) with the non-woven fabric.  
Smooth down the Magic Tape on all four sides of the Seat by hand.

### Step 4




Position ARMLESS SOFA right side up.  
Align the mounting positions on the Seat Frame (A) .  
Insert the Backrest (B) into the Seat Frame (A) as shown in above picture.

### Step 5



Put the Back Cushion(C) on the ARMLESS SOFA.


### Step 6



Your ARMLESS SOFA is ready for use.  
Your ARMLESS SOFA can only be used on a flat, level surface.


**If you already purchased 2 or more than 2 products, Please read on**

### Step 1




Position the ARMLESS SOFA on level surface,as shown.  
Attach the Connecting Piece(⑥) to Seat Frame(A) using Bolts(③), Spring Washers(④), and Flat Washer (⑤) with Allen Key(②) as shown in the right picture.

## Step 2



Connecting the two sofas by using the pre-fixed Connecting Piece (⑥) as shown in the picture.

## Step 3



**Note:** This is optional step in case we want to connect all sofas in a set together and to match the environment of your home.

## Care & Maintenance

-   ● Do not put hot items directly on furniture surface
-   ● Do not clean furniture with harsh cleansers or polish.
-   ● Do not place furniture under direct sunlight.
-   ● Do not place furniture near heating or cooling vents.
-   ● Do not write on furniture without a padded barrier to protect the surface.
-   ● Do not place furniture outside . For indoor use only .
-   ● Not for commercial use. For residential use only .
-   ● Stains may be removed with mild soap solution and damp cloth.
-   ● Children should not climb or jump on the furniture.

- 
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .