











Wood Table & 4 Chairs

								
A) 1 Table Top	B) 4 Table Legs	C) 4 Chair Seats	D) 8 Back Chair Legs	E) 4 Chair Back Panels	F) 8 Front Chair Legs	G) 40 Machine Screws	H) 8 Wood Screws	I) 1 Allen Wrench

! WARNING: CHOKING HAZARD – Small parts NOT for children under 3 years. Please read instructions completely before assembling. Assemble on a soft, smooth area. Adult assembly required.


1

Assemble chair seat (C) to 2 front legs (F). Use machine screws (G) to fasten, tighten with wrench (I)




2

Assemble chair back panel (E) to 2 back chair legs (D). Use wood screws (H) to fasten, tighten with screw driver (I).




3

Assemble chair back to chair seat (C). Use machine screws (G) to fasten, tighten with wrench (I).



4

Assemble 4 table legs (B) into table top (A). Use 2 machine screws (G) for each leg, tighten with wrench (I).



Cleaning

Use only household soap or mild detergent and warm water. Wipe with damp cloth.

Periodically check for loose screws to avoid accidental injury.

