











ASSEMBLY INSTRUCTION




Loosely hand-tighten screws when fitting the table base; fully tighten all only after the full frame is aligned and assembled.


Parts & Tool List

① x2 	② x4 	③ x4 	④ x2 	
Ax8+1  M8*15mm	Bx8+1  M8*10mm	Cx4  Ø30*M6*15mm	Dx4+1  Ø8*30mm	Ex4+1  M6*12mm
Fx1  S4	Gx1  S5			


1




Dx4



2





Ex4



Fx1


3



Cx4





Bx8




Gx1

x4

4




Ax2



Gx1


5

The foot tube is tilted, and the iron rod is inserted into the tube hole




6

The foot tube is tilted, and the iron rod is inserted into the tube hole





7


The foot tube is tilted, and the iron rod is inserted into the tube hole



8



Ax6



Gx1

9

