




CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.


NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening.

PART LIST AND HARDWARE LIST

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TABLE TOP		1X
B	LEGS (R & L)		4X
C	LONG STRETCHER		1X
D	SHORT STRETCHER		2X
H1	LONG BOLT	7.8*60 mm 	8X
H2	SHORT BOLT	6.3*40 mm 	2X
H3	SPRING WASHER	7.8*13 mm 	10X
H4	BIG WASHER	7.8*19 mm 	8X
H5	SMALL WASHER	7.8*16 mm 	2X
H6	ALLEN KEY		1X
H7	WOODEN PLUG	Ø18 mm 	2X
H8	SCREW	Ø4*50 mm 	4X


Product Dimensions: 48"W x 24"D x 36"H




Weight capacity: 25lbs
WARNING: DO NOT STAND ON TABLE
WARNING: DO NOT OVER TORQUE BOLTS

PREPARATION



Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 10 minutes.
Tools Required for Assembly (included): Allen Key



STEP 1



STEP 2



STEP 3