## USE AND MAINTENANCE

## Use on level surfaces only

Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are ill tight and working properly Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

