













Dog Crate



Missing parts, damages, and any problems in the installation process, please contact us by text or email. Please choose SMS or email as your first choice for communicating with us.



Hardware List

 ① x1	 ② x1	 ③ x1	 ④ x2	 ⑤ x1
 ⑥ x1	 ⑦ x1	 ⑧ x2	 ⑨ x1	 ⑩ x1
 ① x2	 ② x24+1	 ③ x1	 ④ x2	



Installation Steps

1




B X4



C X1

② and ③ can be swapped with each other

2



B X4




C X1


3

Installation Steps

3




4




Wheel A can be locked, and the iron plate on the wheel can be fixed by rotating it firmly

Installation Steps

5





6



Installation Steps

7



8

