


JackonLux

Detachable Motion Sensor Cabinet Light



Model # CP-CL13



How to use the Motion Cabinet Light

The Light has 3 working modes. (ON- OFF - AUTO)

1. Remove plastic protective film from the top of the light, then properly install the detachable battery box.
2. Slide the switch on the light to ON, the light will come on and stay always on. Short press the top round button to change colors from White - Red - Green-Blue. Long press (more than 3 seconds) the top round button to JUMP mode.
3. Slide switch to OFF to turn the light off.
4. Slide switch from ON to AUTO, the under cabinet light will turn on automatically when motion is detected in dark area, it will turn off automatically after approximately 30 seconds when no motion is detected. The light color only can be white in auto mode. Short press the round button on the under cabinet light to select brightness 60%-100%-30%. The cabinet light does not have a memory function. After being turned off and then turned back on, it will go back to 60% brightness white color.
5. Slide the switch to "OFF" to save battery power if you do not use the light for a long time.




Power indicator light

How to charge the Motion Cabinet Light

Please use original power adapter and USB cord to charge the RGB motion plastic under cabinet light, the indicator turns red when the RGB motion plastic under cabinet light is charging, it turns green when the under cabinet light is fully charged.


Note: When remove the battery compartment to charge it, make sure to install it back correctly. The indented part inside the battery compartment should be facing up to ensure proper installation.



Cabinet Light


Battery Box

How to use the remote control




How to install the Motion Cabinet Light


1. Sticks directly to an ironwork type surface.




2. Before installation, please clean the surface first. Attach the iron plates to the magnetic positions and remove the paper from the plates. Then, secure the light in your desired place.




PACKAGE CONTENTS




1 x Cabinet Light




1 x Remote Control



2 x Battery Box
(CP-CL13-B)



2 x Iron Bracket with Adhesive Tape



1 x USB Cord

Specification

| | |
|-----------------------------------------------------------------------------------------------|-----------------------------------------------------------|
| Lumen: 100lm±10%(Daylight) | Battery: 1100mAh (Battery box included) |
| Light Color: RGB+5000K±10% | Charge Time: Approx.2-3 hours (Single unit charge) |
| Weight: 0.45BLS | Product Dimension: 14.6 x 1.6 x 0.72inch |
| Runtime: 100% brightness white color - approx. 3-4 hrs , approx.5-6 hrs in RGB colors. | |

SAFETY INFORMATION

- * Please do not disassemble or modify the led light for any-purpose.
- * Discontinue use if damaged.
- * When charging please check for correct voltage.
- * Do not try to repair item or charger on your own.
- * Clean the light with a soft cloth; Do not spray liquid cleaners or water on the light.
- * Do not burn any of the items

CARE AND MAINTENANCE

Using a wet or dry soft cloth, clean the fixture, never spray any liquid cleaner or water directly onto the product.

WARRANTY

JackonLux provides the 7*24 customer service and we are pleased to hear from you. This product has 36 months warranty. If you have any questions or problems, please call our customer service department at +86-400-883-1913. You could also contact us at support@JackonLuxled.com .