


Assembly Instructions

1. Carefully layout all parts in a line on a smooth surface, and use the following steps to assemble the lamp.
2. Install an E12, Type C, 15 watt bulb (not included) or E12, LED, 1 watt bulb (not included)
Note: For bulb replacement, remove shade and replace the bulb.
3. Install shade (C) into base (A)
4. Plug into the wall outlet for use.
5. Use the in-line switch (B) to turn the item ON and OFF



Note: The pedals on the lamp holder may need to be finessed to ensure the shade fits securely.

CAUTION - Refer to the wattage caution label located near the lampholder for recommended maximum wattage-do not exceed recommended wattage.

Warning - Do not attempt to replace the bulb while the lamp is plugged in to a wall receptacle.

Important Safety Instruction

This portable lamp has a polarized plug (One blade is wider than the other) as a safety feature to reduce the risk of the electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit in the outlet, reverse the plug. If it still does not fit, consult a qualified electrician. Never use an extension cord unless the plug can be fully inserted. Do not alter the plug.



Intertek

Made in India