



RSF Loveseat









LSF Chaise










Upward facing hookslot

Ottoman









Assembly Instructions Sectional

Foot Assembly:

Feet are needed to properly support the frame and to distribute weight evenly. Four feet are supplied for the RSF loveseat, five feet for the chaise, and four feet for the ottoman. The feet are shipped inside a zippered compartment on the underside of the frames.

Installation of Feet:

Remove the feet from the zipper compartments.

Locate the threaded inserts on the underside of the units that are marked for feet placement.

Tighten the feet completely into the threaded inserts of the frame.

Once the feet have been secured into the frame, you are ready to assemble your sectional.

Assemble Sectional:

On the loveseat, there is a downward facing hook slot.

On the chaise, there is an upward facing hook.

Left the loveseat on the open end where hook is located and let the downward hook slide into the upward hook slot.

Assembly complete