

























HARDWARE LIST

A  6×35mm 42(+2)PCS	B  42(+2)PCS	C  6×30mm 12(+1)PCS	D  M3.5×12mm 4PCS	E  M3×14mm 12(+1) PCS
F  15×14×10mm 12(+1) PCS	G  12(+1) PCS	H  M6×25mm 4 PCS	J  M6×12mm 2 PCS	K  2 PCS
L  2 PCS	M  4 PCS	N  M4×4mm 2 PCS	O  M4×9mm 2 PCS	P  M6×12mm 4 PCS


PANEL LIST

1  1PC	2  1PC	3  3 PCS	4  1PC
5  1PC	6  1PC	7  1PC	8  1PC
9  1PC	10  1PC	11  2 PCS	12  2 PCS
13  1PC	14  1PC		




TIPS

1. When installing the product, use a soft surface (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
2. Please try to use a manual screwdriver instead of electric screw driver. A manual screwdriver can be used to better control the tightness of the screws.
3. Do not use any glue.
4. The product is unstable before it is assembled. Please pay attention to the product installation sequence, and align all screws and screw holes before tightening.
5. The structure of this product can not meet the requirements of children climbing.




01

INSTALLATION STEPS


Ax12 

02

Ax8 


03

Ax2 
Bx2 




04



Bx10 



05


Bx10 

06

Ax6 


07

Bx6 
Cx6 




08

Nx2 
Ox2 





09




10

Gx12




11


Dx4	
Kx2	
Lx2	
Px4	



12




13



Hx4	
Jx4	
Mx4	


14

Ax14



15

Bx14 
Cx6 



16

Ex12 
Fx12 

