
11 FT Aluminum Outdoor Cantilever Umbrella with Resin Base



Need help or have any questions? Our Professional Service Team is ready to assist you. Don't hesitate to reach out to us at **service@usavingmall.com** or call us at **949-866-8000** for any support or further assistance. We are committed to providing excellent service.

User Manual

General Guidelines

- Please read the following instructions carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.

Notes

- Personal injury and/or damage to the product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The product must be assembled and used in accordance with the provisions of the manual. The seller does not assume any responsibility or liability with respect to any damage caused by incorrect assembly or improper use.
- Carefully check accessories when opening the package. If anything is missing or damaged, please contact us immediately.
- This parasol is only used for shading and decoration purposes.
- Store the parasol in a dry, sheltered place, such as a garage or basement during high winds, rainy days, and the off-season.
- Never force your parasol open. Umbrella mechanics should open gently and easily.
- Do not use sharp tools or equipment such as a knife or scissors when removing the protective material, as it may damage the product.

Warnings

- Keep children away when assembling the product. Small parts are included in the package; they may be fatal if swallowed or inhaled.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- Keep the parasol away from fire; do not use it during extreme cold and heat, and severe weather like rainy, windy, snowy days, and hailstorms, etc.
- If the crank becomes too hard to crank, check to see if the rope has come off the pulley. If you continue to turn the crank, the rope or crank handle could break.
- To prevent damage to the canopy, open the umbrella facing the opposite.

direction that the wind is blowing.


Daily Maintenance

- Clean the canopy with a soft cloth moistened with a neutral detergent. Store it after completely drying, which will help reduce the growth of mold.
- Do not machine wash, do not dry.
- Do not iron.

Contents

Package Contents 3
Preparation 4
Hardware Contents 4
Assembly 5-7
Operation 8-9
Care and Maintenance 10

Package Contents



Part	Description	Quantity
A	Blow Molded Base Outside (with cap)	2
B	Blow Molded Base Inside (with cap)	2
C	Lower Cross Leg	1
D	Upper Cross Leg	1
F	Holder Pole	1
G	360° Swivel	1
N	Umbrella Frame (with canopy)	1
7	Glide Handle	1
L	Pole Support Cap	1
M	Cap for Blow Molded Base	4






PREPARTION

CAUTION: Do not use sharp tools to remove the protective material, as it may damage the product.


Before assembling make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Tools required for Assembly: Wrench and Phillips-head screwdriver (not included)


Hardware Contents

Part	Picture	Description	Quantity
GG		Hex Bolt M10-1.5x20 A2-70	4
KK		Hex Bolt M10-1.5x25 A2-70	4
HH		Flat Washer M10 A2-70	8
JJ		Hex Bolt M8 A2-70	2
I		Hexagon Wrench M8	1
E		Hexagon Wrench M10	1

ASSEMBLY




Step 1: Place the Lower Cross Leg (C) on a flat surface. Align the notches and position the Upper Cross Leg (D) directly over the Lower Cross Leg (C) to form a cross base.



Step 2:
First, attach the 360° Swivel (G) to the assembled Cross Legs. Secure it using the Long Bolts (HH) and Washers (KK), tightening them with the Hex Wrench (E).


Next, mount the Holder Pole (F) onto the 360° Swivel (G). Secure it using the Short Bolts (GG) and Washers (KK). Ensure all bolts are firmly tightened before proceeding.

WARNING: Do not use this umbrella during periods of high winds and rain. Failure to do so may result in personal injury and/or damage.




Step 3: Using the Hex Wrench, remove the Screw and the Inner Collar from the Holder Pole (F).


Important: Keep these parts safe. You will need to re-install them in Step 6.




Step 4: Fill each Base Section (A & B) completely with sand or water and secure with Caps (M).
Safety Warning: To ensure stability, each section must weigh approximately 75 lbs. The total weight of all four sections must be at least 300 lbs.




Step 5: Slide the Pole Support Cap (L) down the Holder Pole (F).
Alignment: Align the arrow on the internal ring with the direction of the Foot Pedal.
Action: Press down on the foot pedal to allow the Cap (L) to slide smoothly into place on top of the base.



Step 6: Re-attach the Inner Collar and Screw (removed in Step 3) back onto the Holder Pole (F). Tighten the screw firmly to lock the assembly in place.



Step 7: Re-insert the screw (removed in Step 3) into the hole on the Holder Pole (F). Tighten it securely to lock the decorative cap in place.





Step 8: Insert the Umbrella Frame (N) into the Holder Pole (F).

- **Align:** Ensure the screw holes on the frame align perfectly with the holes on the pole.
- **Secure:** Insert the two Hex Bolts (JJ) and tighten them firmly using the Hex Wrench.
- **Important:** Ensure the umbrella frame is securely attached before opening the canopy.


OPERATION

Step 1: Unfasten the Storage Strap to release the umbrella canopy.
Note: Ensure the canopy is loose and not tangled before opening.






Step 2: Open the umbrella in two stages:
1.**Extend the Arm:** Squeeze the Glide Handle and slide it UP the pole. Release the handle to lock the arm at your desired angle/height.
2.**Open the Canopy:** Turn the Crank Handle clockwise (to the right) until the canopy is fully open.
3.**Caution:** Do not force the crank. If it feels stuck, check if the canopy ribs are caught on something.



Step 3: 360° Rotation. The umbrella features a 360° swivel base. This allows you to rotate the canopy to track the sun and provide optimal shade throughout the day, without needing to move the heavy base.



Step 4: Operating the Swivel.

1.Step down on the Foot Pedal to unlock the rotation mechanism.
2.While holding the pedal down, rotate the umbrella pole to your desired position.
3.Release the foot pedal to lock the umbrella securely in place.

Care and Maintenance

- Simply clean the umbrella canopy with a soft brush and mild detergent.
- Do not machine wash.
- Do not iron.
- Air dry the canopy thoroughly before storing for extended periods of time.
- Make sure the canopy is completely open during drying process to prevent shrinkage.

Warnings and Cautions



DANGER: Keep children out of the assembly area during assembly.



WARNING: Do not use the umbrella during periods of high winds and rain as this may result in personal injury and/or damage.



WARNING: Be sure to secure and/or weight the base of the umbrella.



WARNING: Always take the umbrella down when not in use.



WARNING: To prevent damage to the canopy, open the umbrella facing the opposite direction that the wind is blowing.

IMPORTANT: If the crank becomes too hard to crank, check to see if the rope has come off the pulley. If you continue to turn the crank, the rope or crank handle could break.

IMPORTANT: Placement of the umbrella over or near a swimming pool can cause premature fading of the canopy. This is not covered under our warranty.