


# ASSEMBLY INSTRUCTION & PARTS IDENTIFICATION

## 70" CONSOLE EBONY OAK




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Part Key					
No	Description	Qty	No	Description	Qty
1	Left Facing Door	2 Pc	7	Hinge	8 Pcs
2	Right Facing Door	2 Pc	8	Door Pull with Bolts	8 Pcs
3	Door Catch	4 Pc		Bolt size 30x6 MM	
4	Shelf Pin 20mm	8 Pc	9	Allen Key 4mm	1 Pc
5	Shelf	2 Pcs	10	Anti Tip Kit	2 Sets
6	Leveler 20x8mm	4 Pcs			

SET UP REQUIRES 2 PEOPLE




STEP 1 : Attach the Door Pulls to the door using the Allen Key provided. See diagram




ASSEMBLY INSTRUCTION &  
PARTS IDENTIFICATION

70" CONSOLE EBONY OAK

STEP 3 : Attach the shelf pin



STEP 4 : Place the shelf on shelf pins



STEP 4:  
PLEASE NOTE : To help prevent the  
possibility of tip-over, install the tip-over  
restraint provided.

