






Assembly Instruction

			LOVESEAT	CHAISE
A		WOODEN LEG	4 PCS	4 PCS
B		WOODEN CENTER LEG	1 PC	1 PC
C		PLASTIC WASHER	1 PC	1 PC





Step 1:

Place the wooden leg (A) on the bottom of the sofa. Tighten the wooden leg (A) by clockwise turning. For wooden center leg (B), please insert plastic washer (C), tighten by clockwise turning. Repeat the same method until all the legs been assembled.



Step 2 :

When all the legs have been assembled, connect the sofa and chaise with hooks the 2 sets of iron corner brackets together.



FOR LEATHER and P.U CLEANING (Code "X")

Clean by lightly brushing and vacuuming only to remove dust and particles buildup. Water based foam cleaner or solvent based cleaning agents of any kind may cause excessive shrinking, staining or distortion of the surface pile and, therefore, should not be used.

FOR FABRIC CLEANING (Code "WW")

- Use water based agents only.
- Do not use solvents.
- Gently remove stains by blotting or hang washing.
- Do not use excessive brushing or rubbing.