BEFORE YOU START


Things You Need To Know

Number of people required to assemble

Two people are required to assemble this item



Time to assemble



Guidelines

FAILURE TO FOLLOW THESE WARNINGS WHEN IN USE COULD RESULT IN INJURY




- We suggest you spend a short time reading through the leaflet before you start
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packing materials and place the components on a clean surface to protect them from damage. We recommend using the product packaging to protect your floor during assembly.
- Carefully check that you have all the parts before beginning assembly.
- Due to the size of this product, we recommend assembly in the room intended for use.
- Make sure the product is fully assembled as illustrated and that all connections are fully tightened before use.
- Wipe occasionally with a soft, damp cloth then buff dry with a soft clean dry cloth.
- The wood will mellow and change color over time. As a result, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent an uneven mellowing.
- Check all bolts and screws every 90 days. As necessary tighten if any are loose.
- Keep small parts and pieces away from children and pets until fully assembled.




- Do not drag or pull your furniture.
- Do not rub or scrub the surface when cleaning.
- Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placement or coaster.
- Do not stand on the item or use as a step ladder.
- WARNING:DO NOT LET CHILDREN PLAY IN OR AROUND THE UNIT DUE TO THE POSSIBLE RISK OF INJURY.

Product Dimension

Actual product size 22.83" Height x 21.77" Width x 17.17" Depth




Getting To Know Your Product





Things You Need To Know

Components supplied. Please use this guide if you require replacement parts.

Fixtures and fittings supplied (not to scale)










(1) Top Panel x1

(2) Left Side Panel x1

(3) Right Side Panel x1










(4) Shelf Panel x1

(5) Rear Bottom Rail x1

(6) Front Bottom Rail x1








(7) Back Panel x1


(8) Small Front Drawer Panel x1


(9) Small Drawer Left Side Panel x1

Things You Need To Know

Components supplied. Please use this guide if you require replacement parts. Fixtures and fittings supplied (not to scale)









(10) Small Drawer Right Side Panel x1

(11) Small Drawer Back Panel x1

(12) Drawer Bottom Panel x2








(13) Large Drawer Front Panel x1

(14) Large Drawer Left Side Panel x1

(15) Large Drawer Right Side Panel x1



(16) Large Drawer Back Panel x1

Things You Need To Know

Components supplied. Please use this guide if you require replacement parts.

Fixtures and fittings supplied (not to scale)







(A) Metal Nail x16 M1.8x16mm (Spare x1)












(D) Drawer Buffer Pad x4 10mm

(E) Cam Bolt x16 M6x28mm (Spare x1)

(F) Cam Lock x16 M15x11mm (Spare x1)







(G) Long Screw x4 M4.5x42mm

(H) Runner (Left +Right) CR/CL on side panel DR/DL on drawer x 2set 350mm (I) Foot Pad x4 25



192mm


(J) Handle x2



(K) Handle Bolt x4 M4x19mm




- 1. Ensure all parts have been removed from the carton and place on a protected surface or carpet.
- 2. Check all parts and hardware are the same as the "Parts List."
- 3. Insert 16 x Cam Bolts (E) into Parts 1, 2, 3, 8 & 13 and tighten with a screwdriver (not supplied).



Assembly Instructions



1. Insert 16 x Dowels (A) into Parts 5, 6, 9, 10, 11, 14, 15 & 16.



Assembly Instructions



1. Attach 2 x Runner (H)/CL to Left Side Panel (2) with 6 x Small Screws (C) and tighten with a screwdriver (not supplied).


Note:

A. Please follow the CL mark on Runner (H)/CL to attach to Left Side Panel (2) as below image.

- B. Align Runner (H)/CL with the edge of the board. Fix Screw (C) into the second assembly hole of Runner (H)/CL onto Left Side Panel (2) as below image.
- 2. Attach Runner (H)/CR to Right Side Panel (3) with 6 x Small Screws (C) and tighten with a screwdriver.


Note:

- A. Please follow the CR mark on Runner (H)/CR to attach to Right Side Panel (3) as below image.
- B. Align Runner (H)/CR with the edge of the board. Fix Screw (C) into the second assembly hole of Runner (H)/CR onto Right Side Panel (3) as below image.






- 1. Attach Shelf Panel (4), Front Bottom Rail (5) & Rear Bottom Rail (6) to Left Side Panel (2) as below image.
- 2. Insert 4 x Cam Locks (F) into Panels 4, 5 & 6. Tighten with a screwdriver.








- 1. Attach Right Side Panel (3) to Shelf Panel (4), Front Bottom Rail (5) & Rear Bottom Rail (6).
- 2. Insert 4 x Cam Locks (F) into Panels 4, 5 & 6. Tighten with a screwdriver.





- 1. Attach Top Panel (1) to assembled unit as below image.
- 2. Insert 4 x Cam Locks (F) into Side Panel (2) & (3). Tighten with a screwdriver.






Assembly Instructions



1. Unfold Back Panel (7) & attach Back Panel (7) to assembled unit. Fasten with 16 x Nail (A) with a hammer (not supplied) as below image.

Note: No paper foil side must face to outside.


2. Attach 4 x Foot Pad (I) onto the end of each foot.



Assembly Instructions



- 1. Attach Small Drawer Left Side Panel (9) & Right Side Panel (10) to Small Drawer Back Panel (11) with 2 x Screws (G) and tighten with a screwdriver.
- 2. Attach Large Drawer Left Side Panel (14) & Right Side Panel (15) to Large Drawer Back Panel (16) with 2 x Screws (G) and tighten with a screwdriver.




(G)

Assembly Instructions




1. Slide Drawer Bottom Panel (12) into the groove of the two assembled drawer units.









- 1. Attach Small Front Drawer Panel (8) to small drawer assembled unit.
- 2. Insert 2 x Cam Locks (F) into Panels (9) & (10) and tighten with a screwdriver.
- 3. Attach Large Front Drawer Panel (13) to large drawer assembly unit.
- 4. Insert 2 x Cam Locks (F) into Panels (14) & (15) and tighten with a screwdriver.






- 1. Attach Handle (J) to assembled unit with 2 \times Bolts (K) and tighten with a screwdriver.
- 2. Repeat same step on the other drawer unit.








- 1. Stick the Buffer Pad (D) on the back edge of the Small Drawer Front Panel on both sides.
- 2. Repeat same step on the Large Drawer Front Panel.








- 1. Attach Runner (H)/DR & DL to assembled drawer unit with 6 x Screws (C) and tighten with a screwdriver as below image.
- 2. Repeat same step on the other drawer unit.



Assembly Instructions




1. Insert the assembled Small & Large drawers into the unit as below image.



Assembly Instructions





Periodically (every 90 days) make sure that all screws are still fully tightened. **ATTENTION**: Be certain that all screws are fully tightened before using this product.

Limited Warranty

The product you have purchased is warranted against defects in material and workmanship while owned by the "Original Purchaser." The term "Original Purchaser" is defined as the party or entity that purchases these products from and authorized dealer or retailer as shown by the original sales receipt. The warranty does not apply to "as is" or previously owned products.

The manufacturer warrants its products to be free from defects in materials and workmanship (normal wear and tear, fading and stretching excepted), for one year from the date of purchase, except as provided below under the limited warranty.

This warranty gives you specific rights, and you may also have other rights, which vary from state to state (or country to country). All warranties are limited to the Original Purchaser for normal use by a maximum of two users. Total weight capacity per chair is 250 pounds for a single user.

The exceptions or exclusions to this warranty are:

- Upholstery material and foam cushion material is warranted against defects in material and workmanship for a period of one year, beginning on the date of purchase as shown on the original sales receipt.
- Any warranty claim that is submitted after the limited warranty period, or without proper proof of purchase will not include the cost of parts, labor, or delivery on the warranted parts within a reasonable amount of time. We reserve the right to require damaged parts to be returned to us upon request. Natural markings such as scars, brands, grain variations, wrinkles, color variations, etc. will be considered normal characteristics and not construed as defects.