


A4双面黑白 105克铜版纸

illeadzm


TV STAND

TSY1700




A1	 (8X50mm)	8PCS	C3	 (8X18mm)	4PCS	F	 (5X60mm)	2PCS
A2	 (M8)	4PCS	C4	 (10mm)	4PCS	G1	 (M5)	1PCS
B1	 (6X50mm)	4PCS	D1	 (4X16mm)	4PCS	G2	 (M6)	1PCS
B2	 (M6)	4PCS	D2	 (5X16mm)	4PCS	G3		1PCS
C1	 (5X14mm)	4PCS	E1	 (6X25mm)	4PCS			
C2	 (6X18mm)	4PCS	E2	 (8X30mm)	4PCS			


1. Installation the four trundles of the base




3. Install the tray




2. Fix two stand columns



4. Install the hanging plate



5. Install two brackets to the back of the TV



6. Hook the TV brackets to the hanging plate, and then tighten the two screws to fix it.

