
















Assembly Instructions

SIT OR STAND ADJUSTABLE DESK



IMPORTANT ASSEMBLY INSTRUCTIONS:


DO NOT TIGHTEN SCREWS COMPLETELY
UNTIL BOOKCASE IS FULLY ASSEMBLED

NO.	PART	DESCRIPTION	Q'TY	NO.	PARTS	DESCRIPTION	Q'TY
A		Top	1 PC	B		Connecting rod	1 PC
C		Leg	1 PC	D		Leg	1 PC
E		Stretcher	2 PC	F		Stretcher	1 PC
G		Crank Wheel	1 PC	H		Allen Head Bolt 8mm 50mm	2 PC
I		Allen Head Bolt 8mm 20mm	8 PC	J		Allen Head Bolt 8mm 16mm	9 PC
K		Hexagonal Nut 8MM	6 PC	L		Allen Head Wrench 5mm	1 PC
M		Open-end Wrench	1 PC	N		Handle	1 PC


Assembly Instructions

STEP1


SIT OR STAND ADJUSTABLE DESK



STEP2



STEP3




IMPORTANT ASSEMBLY INSTRUCTIONS:

DO NOT TIGHTEN SCREWS COMPLETELY
UNTIL BOOKCASE IS FULLY ASSEMBLED


Assembly Instructions

SIT OR STAND ADJUSTABLE DESK



STEP 4



STEP 5



STEP 6



IMPORTANT ASSEMBLY INSTRUCTIONS:

DO NOT TIGHTEN SCREWS COMPLETELY UNTIL BOOKCASE IS FULLY ASSEMBLED