








ASSEMBLY INSTRUCTION








Porch Swing With Stand







Component List

LABEL	ILLUSTRATION	DESCRIPTION	QTY
A		Front left leg tube	1
A1		Front right leg tube	1
B		Rear leg tube	2
C		Leg connecting tube	2
D		Rear foot horizontal	1
D1		Rear foot horizontal	1
E		Rear foot horizontal(flat)	1
E1		Rear foot horizontal(flat)	1
F		Middle canopy tube	1








Component List

LABEL	ILLUSTRATION	DESCRIPTION	QTY
G		Side canopy tube	4
I		Left armrest	1
I1		Right armrest	1
J		Seat board	1
K		Canopy bent tube	2
L		Canopy straight tube	2
M		Ceiling cloth	1
N		Seat cushion	3
O		Rear support bracket	2

Component List

LABEL	ILLUSTRATION	DESCRIPTION	QTY
P		Ceiling bracket	2
Q		Plastic finial	4
Q1		Plastic Y-Connector	2
Y		Large handwheel	2

Hardware List



LABEL	ILLUSTRATION	DESCRIPTION	QTY
1	 M6X45	Bolts+Washers +Nut	+1 (spare) 4
2	 M6X40	Bolts+Washers +Nut	14
3	 M6X35	Bolts+Washers +Nut	2
4	 M6X70	Bolts+Washers +Nut	4
5	 M8X80	Bolts+Washers +Nut	+1 (spare) 4
6	 M8X65	Bolts+Washers +Nut	2
7		Allen key	1
8		Bilateral opening	1

1

2×10PCS



M6X40

7




Step 1 Attach the Leg Tubes

Pay attention to the orientation




Step 2 Attach the Leg connecting tube



2

3×2PCS






M6x35


7



8


**H**

Insert the Tapered Rear Feet
into the Straight Rear Feet



3

4×4PCS






M6X70

7




8




H

Attach the Rear foot horizontal



4


2×4PCS



M6x40

x2




O×2PCS



7




8




H

Step 1



Step 2




5

5×4PCS



M8x80

6×2PCS






M8x65


7




8



Step 1 Install the seat




Step 2



6

1×4PCS






M6x45


7




8



Y×2PCS




Install Ceiling bracket and Canopy bent tube
tighten all screws




7


Q×4PCS



Q1×2PCS




Connect the Canopy
using the Plastic Connector






Step 1



Step 2

Install the swing canopy




! ATTENTION

To adjust the angle of the canopy, please loosen the knobs on both sides, then align the gears and tighten.

Step 1

Install seat cushion



Step 2

Put down the lounge chair



Turn the pull-out button to detach the seat

1. Tighten all screws after assembly to prevent loosening or falling.
2. Children must use under adult supervision; keep clear of obstacles.
3. Check suspension and connections regularly for safety.