




Zebra Shades


INSTALLATION INSTRUCTIONS

CORDLESS ZEBRA SHADE


	A: 2 brackets
	B: 4 Screws
	C: 4 Stoppers
	D: 1 Handle

Before installing the shutters, make sure all parts listed below are present. Do not assemble, install or operate if any parts are missing or damaged. For replacement parts, Please call Customer Service to locate missing or damaged parts.

INSTALLATION MANUAL




INSIDE MOUNT





OUTSIDE MOUNT

Place the pegs




peg free for wooden window frames

Place the brackets




Hook the rail onto the bottom of the bracket and rotate it until the back of the rail securely snaps into place




LIGHT CONTROL


Light filtering Mode



Full Close mode




Regulation mode



HOW TO USE

Featuring an Free-Stop systems technology for quick, accurate and nimble control. Raise and lower with no additional pulling or tugging.




PLEASE RECYCLE

Guarantee applies to workmanship and materials only, product photos are for illustrative purposes only.

MADE IN CHINA

OUR ADVANTAGE



**Upgraded Aluminum
Valance and Bottom Rod**

**Three ways to
regulate light**



Free-Stop Cordless System

**Frosted Handles Have
a Remarkable Texture**



• If you are satisfied with our products, pls don't hesitate to recommend our store to your friends!

• If you have any questions, pls feel free to contact us by email for after-sale service.