


ITEM:3 STEP LADDER





Precautions:

- 1) The product is only suitable for single support not for industrial use
- 2) Check carefully whether the product is defective before use, if there is an abnormality, do not use.
- 3) Do not put your hand on the step when closing, to avoid squeezing your fingers
- 4) After use, store it in a cool and dry environment.
- 5) Do not allow children to climb or play at will; Stay away from fire hazard place.



- A: Do not allow children to climb or play arbitrarily
B: Prohibited to use on non-level ground
C: This stepstool conduct electricity
D: Climbing is prohibited when the top is standing

Accessories



(B)*1



(C)*2



(D)*2




(E)*1




(F)*1


Installation




Put the ladder vertical erect and spread it steady on the floor.



Remove the cap with spanner (F) prying.




Insert the handrail.



Install the screw nuts to secure the handrail.

Instructions for use:

Unfolding ladder




Put the ladder vertical erect.

Hold the left side of the ladder tith your left hand, use one foot to lift the back feet of ladder then spread it.

Support the feet of ladder to the limit to unfold it fully.

Folding ladder



Note: Before retracting, the front legs should be perpendicular to the ground

Locking button

Place the front legs of the ladder perpendicular to the ground first.

Hold the left side of the ladder, push the locking button and fold the ladder.

The legs of ladder is parallel when ladder is fully folded.