



To fully enjoy the comfort and functionality of your new sofa, please follow these steps to help it regain its original shape after unboxing:

1. **Pat the Sofa:** Gently pat the sofa on each side several times to assist in reshaping it. Start by patting one side, then repeat on the other.
2. **Flip the Sofa:** Turn the sofa over and repeat the patting process to ensure even reshaping on all sides.
3. **Rotate the Sofa:** Rotate the sofa 180 degrees so the back is facing down, and repeat the patting to further restore its shape.
4. **Secure the Sofa:** Attach the Velcro strips to the bottom of the sofa to keep it securely in place and prevent separation.
5. **Lightly Tap and Press:** Lightly tap, knock, and press on the sofa to help it regain its original shape and improve overall comfort. improve overall comfort
6. **Smooth the Fabric:** If wrinkles appear on the sofa fabric, use a garment steamer to smooth them out for a more polished appearance

