ASSEMBLY INSTRUCTIONS


Thank you for you purchase.

Before assembly, please read these instructions.

Please read all warnings.

Store this instruction manual for future reference.

Product Size	Approximately 450 Width x 1440 Length x 1320 Height (MM)
Main	, , , , , , , , , , , , , , , , , , , ,
Materials	MDF (Medium Density Fiberboard)
Weight Capacity	Top insert: About 30KG, Shelf insert: About 10KG, X These are measured figures, not guaranteed figures.
Capacity	* These are measured figures, flot guaranteed figures.
Time To Assembly	About 30 Minutes




Assembly Warning


- Assembling with 2 or more people is recommended.
- Please assemble at a spacious and flat place
- Please place blankets or cardboard so floor or walls will not be scratched
- Please ventilate the area if there is a strong glue odor after opening the product
- Please follow assembly instructions
- Please have the below tools ready before assembling
 - Screwdriver, Scissors or Blade Box cutter, Rubber hammer, Drill

Hardware

Before assembly, inspect unit for missing parts. Be sure that children do not accidentally swallow these parts. **Same sized parts are in a bag. Please check the size of the screws.



Parts




1 Desktop Panel	1 Pc
2 Left Side Panel	1 Pc
3 Back Panel	1 Pc
4 Stand Panel	1 Pc
5 Box Top Panel	1 Pc
6 Box Bottom Panel	1 Pc
7 Left Box Side Panel	1 Pc
Right Box Side Panel	1 Pc
9 Box Support Panel	1 Pc
Box Back Mdf Bord	2 Pcs
11 Door Panel	2 Pcs
Left Above Side Panel	1 Pc
Right Above Side Panel	1 Pc
Right Above Shelf Panel	3 Pc s
Above Back Mdf Board	1 Pc

Assembly Information





Assemble Wood Dowels
 Assemble Minifix





Assembly Step


Failure to follow these directions could cause poor strength or stability. Insert screws loose to line up with slots then tighten up each screw.















06









Safety

Please read the below warnings before use.

Failure to follow these warnings could result in serious injury.



CAUTION!!!

Purpose

- Do not use this unit except for original application
- This unit is for household use. Do not use it for wholesale.
- This unit is for indoor use. Do not use it outside.

Assembly

- Assembling with 2 or more people is recommended
- Please assemble at a spacious and flat place
- Please place blankets or cardboard so floor or walls will not be scratched
- Please ventilate the area if there is strong glue odor after opening the product
- Please follow assembly instructions

Placing The Unit

- Store the unit on a flat surface.
- Place a mat under the unit if you place it on wood floors for floor protection
- Do not place the unit in areas where conditions are extreme, such as direct sun or a humid place
- Do not place the unit in a hot or humid area, such as near the heater or fireplace

Usage

- Please check your surroundings when you use this unit
- Do not place any hot or wet objects on the unit
- Remove all objects on the unit when you move it
- Do not leave water or wet objects on the surface.
- Do not use it for toys
- Do not stand on it or use it for a step stool.
- Do not overload only the top drawers. Load the same amount to help prevent tipping of the unit.
- Do not leave drawers open or put pressure on opened drawers to help prevent falling or wrecking.
- Do not stand or put pressure on opened drawers.
- Colors could fade
- Please open drawers slowly
- Make sure you do not catch your finger when you use the drawer.
- Weight Capacity Top insert: About 30KG,
 Shelf insert: About 10KG,
 These are measured figures, not guaranteed figures

Cleaning


- Please check all assembled parts are tight regularly. (About once a month)
- Use dry soft cloths for dust and spots
- For heavy spots, use clothes with neutral detergent then dry in a well ventilated area.
- Do not use if any parts are broken.
- Please recycle the unit or its package depending on your city rules.

the top.

HOW TO ADJUST GLASS/DOORS


• There is a gap between the door and the shelf with doors closed

Loosen the back adjustable screw which is one of the two screws looking from the front while supporting the doors, adjust the door by moving it back and forth, then tighten the back screw.



• There is a gap in the middle with doors closed


Loosen the (1) back adjustable screw which is one of the two screws looking from the front while supporting the doors, tighten the ② screw clockwise, then adjust the middle gap. After adjusted, tighten the ① screw.



• There is a gap on the top of the door when doors are closed (Glass slide hinge does not require this step) (4 screw hole hinge does not require ①)

Loosen the slide hinge screw while supporting the door, adjust the door by moving it up and down then tighten the screws.

(Please loosen the slide hinge screws of the door completely you are adjusting before moving it up and down.)



There is a V gap when doors are closed

Loosen the ①back adjustable screw which is one of the two screws looking from the front while supporting the doors, tighten the ② screw clockwise, then adjust the middle gap. After adjusted, tighten the ① screw.

