
ASSEMBLY INSTRUCTION

41.25"H SET OF 2 CHRISTMAS 3D FABRIC GINGERBREADMAN WITH 120 WARM WHITE LED LIGHTS











Please carefully unpack and identify each component before beginning assembly. Before you begin, please refer to parts list to make sure that you have all parts. Please take care when assembling the unit and always place the parts on a clean, soft surface. If you require assistance with assembly or parts.

BEFORE ASSEMBLING

1. Please check and make sure all the parts have been received.
2. Tools are not required for assembly.
3. The length of extension cord is 98 inch, please set up the product in the suitable place away from the power socket.


PART LIST

Base (A)  QTY: 2	Lower body (B)  QTY: 2	Upper Body 1 (C)  QTY: 1	Upper Body 2 (D)  QTY: 1
Hat (E)  QTY: 1	Hands (F)  QTY: 4	Tree (G)  QTY: 1	Candycane (H)  QTY: 1
Screw (I)  QTY: 2	Adapter (J)  QTY: 1	Zip Ties (K)  QTY: 10	Lawn stakes (L)  QTY: 4


STEP-BY-STEP ASSEMBLY

PLEASE CAREFULLY UNPACK AND IDENTIFY EACH COMPONENT BEFORE BEGINNING ASSEMBLY. BEFORE YOU BEGIN, PLEASE REFER TO PARTS LIST TO MAKE SURE THAT YOU HAVE ALL PARTS.


STEP 1 Insert the lower body into the base and lock with the supplied screw.



STEP 2 Connect the light between the upper and lower parts. Then insert the upper body into the lower body and lock the metal rings with the zip tie.



- STEP 3** Insert the hat on the boy's head as shown. Assembly finished. Connect the light chain of two gingers and light up with the supplied transformer.
- For outdoor use, secure the unit onto the ground by inserting the ground stakes.



DISASSEMBLY AND STORAGE

1. Remove all decorations.
2. Disassemble the product in reverse order of assembly.
3. Suggest to store it in its original carton box or in storage bag and keep in a cool dry place.

CAUTION

1. To be assembled by or under the supervision of an adult.
2. Keep plastic bags out of reach of children.
3. Keep away from fire or hot temperatures.
4. Do not light a candle on or near the product.
5. Do not leave lighted electric cords unattended.
6. When assembling, do not let children play around the working area.
7. Place the product on an even surface to ensure stability.
8. Keep this information for future reference.
9. Please periodically check all fittings and re-tighten as necessary.

Made in China