











Massage Recliner Assembly Instruction

A 	B  X2	C 	D 	E 	F  X2	G  X4	H 
Backrest	Armrest	Chair base	Lift control	Power source	Parts	Parts	Massage control




Power Lift Recliner Assembly Instructions

STEP 3

No.1 and No.2 wires from the backrest and chair base with same color connect together.
No.3 wire from the back connects to the wire at the bottom of the sofa.

The USB socket in the bottom of the sofa armrest.




Massage Recliner Assembly Instruction

How to recline?




How to get footrest latch down and stand?



Massage Recliner Assembly Instruction

How to use remote control?



You can choose 1-4 massage parts(back,lumbar,thighs,legs)to enjoy

ON/OFF:Turn on/off remote control

HEAT:Turn on/off heat function for lumbar part only

INTENSITY:Control massage funcion from low to high

MODE:Choose one massage mode you like(pulse,press,wave,auto,normal)

Massage Recliner Assembly Instruction

OPERATING YOUR CHAIR

Lift (Up)

- Press and hold the button to raise the power lift chair.
- Release the button when the power lift chair reaches a height where you can stand up comfortably.

Lift (Down)

- Press and hold the button to lower the power lift chair to seated position.
- Press and hold the button to raise the footrest and lean back to a comfortable reclining position.

Power Headrest (Tilt)

- Press and hold the button to tilt the power headrest to a comfortable position.

Power Headrest (Back)

- Press and hold the button to back the power headrest to the original position.

Flashlight

- Press and the “Light” button to back the power headrest to the original position.

