


Cabinet

Assembly Instruction – Please keep properly for future reference.

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.



CONTACT US

- In order to receive assistance more quickly, please provide

THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)

EN

Important – Please read these instructions carefully before starting the installation.

Before Assembly



Thank you for choosing our product!

To ensure a smooth installation process, please read this guide carefully to familiarize yourself with the required tools, materials, and installation steps.

Follow the relevant sections to avoid any damage caused by improper installation, and make sure to review all operation and safety guidelines for correct installation procedures.

Packaging Notice:

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.

Safety and Care Advice



Important :

Please read these instructions fully before starting assembly.

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal center.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.

Warning

In order to help prevent overturning, please follow these instructions.

- Use the anti tip strap or wall fixing method provided (if applicable).
- Do not allow children to climb or hang on the furniture.
- Do not open more than one drawer at a time.
- Do not place heavy items in the top drawers.
- Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose.
- Please note that only the anti tip strap is provided. You will need to provide wall plugs and screws applicable for your wall type.

Customer Service Guide



Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the “Parts List” in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., “Missing 5 pieces of M6×30mm screws.”

Contact Us:

By Email:

Send an email with the subject line “Missing Parts Issue.” Include the following in the email:

- A description of the missing parts and a photo of the parts list.
- Order details (order number, purchase platform, purchase date).

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multi-angle shots are recommended).
2. Email the photos/videos along with order details to with the subject line “Product Damage Issue.”

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:**Steps:**

1. Contact our customer service team.
2. Provide a description of the damage and include relevant photos or videos.

Resolution:

We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Helpful Tips**To process your issue efficiently, please prepare the following information:**


- Order details (order number, purchase platform, purchase date).
- Clear photos or videos.
- We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.

Thank you for your trust and support!
We hope you enjoy using our product!


Parts List – Panels




Please check you have all the panels listed below.




1 760*465*15mm **x1**




2 760*465*15mm **x1**




3 562*25*15mm **x1**




4 564*120*36mm **x1**




5 564*420*15mm **x1**




6 564*110*15mm **x1**




7 564*110*15mm **x1**




8 630*305*15mm **x1**




9 596*467*15mm **x1**




10 466*75*15mm **x1**



11 466*75*15mm **x1**



12 564*75*15mm **x1**



13 630*305*15mm **x1**








Parts List - Fittings



EN

Please check you have all the fittings listed below.

Note: The quantities below are the correct amount to complete the assembly.
In some cases more fittings may be supplied than required.

		
A Ø7x39mm x22	B Ø15x12mm x22	C Ø8x30mm x13
		
D Ø3.5x14mm x8	E Ø5x40mm x6	F Ø4x14mm x4
		
G Ø8x50mm x4	H Ø6x30mm x3	I Allen Key x1
		
J Door pin x6	K L shape bracket x2	L Protective Foot x4
		
M Pulley x2	N Wall Fixing Pack x2	O Sink x1


Tools required



Phillips screwdriver
(medium & large)

Ruler

Use this ruler to
help correctly
identify the screws



The screws length is measured from the head to the point
(30mm screw shown).


Using Camlocks



Step 1


Connect the male camlock as directed in the assembly instructions using a screwdriver.

DO NOT OVER TIGHTEN.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.



The joint is now secure.




Assembly Instructions



EN




Step 1



Attach cam bolt (A) to part (1, 2).


Step 2



Insert wooden dowel (C) to part (4).

Step 3


B 
 Ø15x12mm x2



Attach part (4) to part (1), then insert and secure cam lock (B) to part (4) to lock it.

Step 4



C 
 Ø8x30mm x4



Insert wooden dowel (C) to part (5).

Step 5


B 
 Ø15x12mm x2



Attach part (5) to part (1), then insert and secure cam lock (B) to part (5) to lock it.


Step 6

C 
 Ø8x30mm x5




Insert wooden dowel (C) to part (6, 7).

Step 7




Attach part (6, 7) to part (1), then insert and secure cam lock (B) to part (6, 7) to lock it.

Step 8




Attach part (2) to part (4, 5, 6, 7), then insert and secure cam lock (B) to part (4, 5, 6, 7) to lock it.

Step 9




Step 10

G 
Ø8x50mm x4




Insert wooden dowel (G) to part (1, 2).

Step 11



Attach cam bolt (A) to part (9).

Step 12




Attach part (9) to part (1, 2, 6, 8) using screw (E).

Step 13

A  $\varnothing 7 \times 39 \text{ mm}$ x2



C  $\varnothing 8 \times 30 \text{ mm}$ x2



Attach cam bolt (A) to part (10, 11).
Insert wooden dowel (C) to part (12).

Step 14

B  $\varnothing 15 \times 12 \text{ mm}$ x2



Attach part (10, 11) to part (12), then insert and secure cam lock (B) to part (12) to lock it.

Step 15



EN

B





Ø15x12mm

x4




Attach part (10, 11, 12) to part (9), then insert and secure cam lock (B) to part (10, 11) to lock it.

Step 16




Use L shape bracket (K) and screw (D) to attach part (10, 11) to part (9).

Step 17




Insert protective foot (L) to part (10, 11, 12).

Step 18





Insert door pin (J) to part (8).

Step 19





Place door (8) on the track.

Step 20




Attach part (3) to part (4) using bolt (H) with allen key (I).

Step 21




Insert door pin (J) to part (13).

Step 22



Place door (13) onto the part (9).




Step 23



Place pulley (M) on the bar, and then attach pulley (M) to door (13) using screw (F) with a screwdriver.

Step 24**N**


Wall Fixing Pack x2



Secure the cabinet to the wall by using appropriate wall plugs and screw (N).


Step 25

EN



Sink

x1



Apply a thin layer of silicone sealant around the top of the vanity, and then carefully secure the sink (O) in place.
Remove excess silicone sealant with a damp rag.