


COFFEE TABLE



SKU: LTCZ5615

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

www.domioutdoorliving.com

WARNINGS

1. **Read and understand all instructions.** Failure to follow all instructions may result in injury and/or damage.
2. **The warnings, cautions, and instructions discussed in this manual cannot cover all possible conditions or situations that may occur.** The user must always be aware of their environment and ensure that they use the product in a safe and responsible manner.
3. **Do NOT modify the product in any way.** Unauthorized modification may impair the function and/or safety of the product, and may affect the life of the product. Any modifications will void warranty.
4. **Check for damaged parts.** Before using this product, carefully check that all parts are in good condition, and that the product will operate properly and perform its intended function. Check for damaged parts and any other conditions that may affect the operation of this product. Replace damaged or worn parts, and never use this product with a damaged part.









5. **Do NOT overload the product.**




Total weight capacity	350 lb (evenly distributed)
-----------------------	-----------------------------

6. **Do NOT sit or stand on the tabletop.** Tipping may occur causing injury.
7. **Do NOT allow children to climb onto or hang from the table.**
Tipping may occur causing injury.
8. **This is made with UV-stabilizers to minimize fading, however, upon exposure to the sun, all colors will fade to some degree.** To minimize possible fading: keep product covered, utilize cushions where applicable, minimize direct sunlight by storing product when not in use, or use a UV-protectant.


CARE AND MAINTENANCE


- Avoid harsh, abrasive cleaners, and other corrosive chemicals.
- Do not use metal scouring pad for cleaning. Most stains can be removed by using a mild soap and a soft-bristled brush.
- Avoid placing any direct heat source on or near the surface.
- Leaving any glassware on Chair under sunlight may result in burn marks on the surface. Please use a coaster when placing glassware on Chair .
- When not in use, cover the product with a protective cover to keep it clean and prolong its lifespan.

 A Table Panel 1X	 B Long Crossbar 2X	 C Short Crossbar 2X
 D Table Leg 4X		
 1 M6*60mm Bolt 4X	 2 M6 Nut 4X	 3 D6 Washer 4X
 4 ST6*35mm Screw 8X	 5 ST6*60mm Screw 4X	 6 ST6*90mm Screw 8X
 7 ST6*110mm Screw 4X	 8 Spanner 1X	 9 Allen Key 1X
Sofa should include the following parts. Please inspect box contents to ensure you have received all components. If you are missing any parts, need assistance with assembly or have questions, please contact our Customer Service.  USA & Canada: 1-833-807-3550		


	2X
	4X
	4X
ST6*110	

Step1 Assemble Legs




	1X
	4X
	4X
	4X
1	

Step2 Attach Tabletop



Do not overtighten screws.
(Insert all screws before tighten screws)





ST6*35

4

8X

Step3



B

2X


Step4 Attach Support Panels




ST6*60

5

4X






ST6*90


6

8X

Step5



Step6



Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So, if you have any questions about our product or assembly, please feel free to contact us. We are here for you.

Support:  

After-sales contact email:

service@domioutdoorliving.com

Business cooperation contact email:

marketing@domioutdoorliving.com

Please have your order ID available if you reach out for support.

If you have damaged parts or product, please send us photos for an immediate response.