
User's Manual

Crate



EN

Thank you for purchase on our products. Please contact us if you have difficulty with assembly or need replacement parts. Our customer service is here to assist you.
Please attach your User Name or Order ID so that we can assist you better.

WARNING

Serious or fatal injury may occur from unexpected assembly or use.

1. During the assembly process, keep all parts away from babies or children.
2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.
4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
5. Place the heaviest items on the lowest shelf.
6. Never allow children to climb or bang on drawers, doors or shelves.

DE


Vielen Dank für Ihren Kauf von uns Produkten. Bitte kontaktieren Sie uns, wenn Sie Probleme mit Montage haben oder Ersatzteile benötigen. Wir Kundenservice ist für Sie da.
Bitte geben Sie Ihren Benutzernamen oder Ihre Bestellnummer an, damit wir Sie besser unterstützen können.

WARNUNG
























Bei unerwarteter Montage oder Verwendung können schwere oder tödliche Verletzung auftreten.

1. Legen Sie in den Montageprozess alle Teile weg von Babys oder Kindern.
2. Stellen Sie sicher, dass der gebohrte Wandbereich frei von verborgenen Stromkabeln, Wasser- und Gasleitungen ist, wenn Sie dieses Produkt an der Wand befestigen.
3. Die Verwendung von Kippsicherungen kann die Gefahr eines Kippens nur verringern, jedoch nicht beseitigen.
4. Setzen Sie bitte keine schweren Gegenstände auf dieses Produkt, es sei denn, dass das Produkt speziell für die Unterbringung konzipiert wird.
5. Legen Sie bitte die schwersten Gegenstände auf das unterste Regal.
6. Erlauben Sie nie Kindern, auf Schubladen, Türen oder Regale zu klettern oder zu knallen.

Parts List(EN) / Teile Liste(DE)




Parts List(EN) / Teile Liste(DE)


A  M6×40mm 86+2PCS	**B**  Ø15×9.5mm 86+2PCS	**C**  Ø6×30mm 58+2PCS	**D**  M6×33mm 8+1PCS
E  M5×40mm 10+1PCS	**F**  **F-1** **F-2** 50×36mm 2SETS	**G**  **G-1** **G-2** 50×36mm 2SETS	**H**  M6×28mm 4+1PCS
I  2PCS	**J**  M6×10mm 8+1PCS	**K**  M6×12mm 4+1PCS	**L**  M6×25mm 8+1PCS
M  2SETS	**N**  Ø30mm 5PCS	**O**  M4×18mm 5PCS	**P**  Ø35mm 4PCS
Q  Ø30mm 2PCS	**R**  M4×14mm 44+2PCS	**S**  M3×16mm 20+2SETS	**T**  M4×10mm 40+2PCS
U  M3.5×12mm 16+2PCS	**V**  Ø5×15mm 16+2PCS	**W**  37×36mm 2PCS	**X**  117mm 4PCS
Y  Ø11×15mm 4+1PCS	**Z**  Ø6×90mm 2SETS	**C2**  Ø6×60mm 2PCS	**V2**  Ø5×16mm 4+1PCS
V3  Ø21mm 28+2PCS	 2PCS	 1PC	


Assembly Steps(EN) / Montageschritte(DE)

STEP 1





Turn over part (4) to install the other side.



	**A** x 10PCS

STEP 2







	**B** x 2PCS
	**C2** x 1PC

Assembly Steps(EN) / Montageschritte(DE)


STEP 3





	B x 6PCS
	C x 2PCS


STEP 4




	C2 x 1PC


Assembly Steps(EN) / Montageschritte(DE)

STEP 5




	**A** x 8PCS


STEP 6



Assembly Steps(EN) / Montageschritte(DE)


STEP 7






	B x 2PCS
	C x 4PCS

STEP 8







	B x 4PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 9



STEP 10





	**B** x 4PCS
	C x 4PCS




Assembly Steps(EN) / Montageschritte(DE)


STEP 11



 **A** x 4PCS


STEP 12




 **A** x 12PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 13






	B x 4PCS
	C x 4PCS

STEP 14







	B x 4PCS
	C x 4PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 15



STEP 16





	**B** x 8PCS
	**C** x 8PCS




Assembly Steps(EN) / Montageschritte(DE)


STEP 17



	**A** x 26PCS

STEP 18







	**B** x 12PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 19




	**B** x 14PCS
	**C** x 14PCS




STEP 20




	**A** x 6PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 21





	B x 6PCS
	C x 6PCS


STEP 22



	D x 4PCS
	E x 4PCS
	1PC


Assembly Steps(EN) / Montageschritte(DE)

STEP 23




	L x 4PCS
	1PC


STEP 24




	L x 2PCS
	1PC


STEP 25



	**A** x 10PCS

STEP 26







	**B** x 4PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 27






	B x 6PCS
	C x 6PCS
	L x 2PCS
	1PC

STEP 28




	A x 10PCS
	D x 4PCS
	E x 6PCS
	1PC


STEP 29




	B x 6PCS
	C x 6PCS
	V3 x 28PCS




STEP 30



	B x 4PCS
	S x 20SETS




STEP 31




	**V** x 16PCS

Assembly Steps(EN) / Montageschritte(DE)

STEP 32







	**P** x 4PCS
	**R** x 8PCS
	**O** x 2PCS
	**N** x 2PCS

x2

STEP 33







	**R** x 16PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 34






	**Q** x 2PCS
	**R** x 4PCS
	**O** x 1PC
	**N** x 1PC

STEP 35






	**R** x 8PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 36




	F-2 x 2PCS
	I x 1PC
	T x 6PCS

STEP 37




	F-1 x 2PCS
	I x 1PC
	T x 8PCS

STEP 38




Assembly Steps(EN) / Montageschritte(DE)

STEP 39




	G-2 x 2PCS
	I x 1PC
	T x 6PCS

STEP 40




	G-1 x 2PCS
	I x 1PC
	T x 8PCS

STEP 41




Assembly Steps(EN) / Montageschritte(DE)

STEP 42



	Z x 1SET
	T x 6PCS


STEP 43



	Z x 1SET
	T x 6PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 44



	J x 8PCS
	1PC


STEP 45



	Y x 4PCS
	H x 4PCS
	1PC


Assembly Steps(EN) / Montageschritte(DE)

STEP 46



	X x 4PCS
	W x 2PCS
	U x 16PCS
	V2 x 4PCS
	R x 8PCS
	O x 2PCS
	N x 2PCS


STEP 47




Assembly Steps(EN) / Montageschritte(DE)


STEP 48

Lock the long side of the "**M**" L-shaped metal plate to the ① board with the "**M**" short screw.






Please lock the 4 "K" of screws, otherwise the doors might fall out.




	K x 4PCS
	M x 2SETS
	1PC

STEP 49

Drill 2 holes on the wall at the required position for anti-falling device installation.






	M x 2PCS

STEP 50

Lock the long side of the "**M**" L-shaped metal plate to the ① board with the "**M**" short screw.




	M x 2PCS


The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.


Components Name



Obvious gaps between doors or Doors don't look closed



1 Turn "internal & external screw" to the right can make the door approach inside. Please adjust the doors little by little.




※ If the 2 doors are overlap, please turn the "internal & external screw" to the left.

When door is crooked




Please take the following steps to adjust first.

1 Rotate the "front and rear screws" to the left




※ After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right Slightly.


2 Push the door to the cabinet




3 Rotate the "front and rear screws" to the right




When door is leaning




1 Turn "internal & external screw" to the left can make the top of the door tilted outward.







1 Turn "internal & external screw" to the left can make the bottom of the door tilted outward.




When the door is higher on top




1 Turn "up & down screw" to the left



2 Lower the door's height so that 2 doors are of the same height.



3 Turn "up & down screw" to the right



※ If the door is lower on bottom, please lift up the left door slightly on step 2

⚠ WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **ALWAYS install Anti-tip device provided.**
- **NEVER put a TV on this product.**
- **NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.**
- **NEVER open more than one drawer at a time.**
- **Place heaviest items in the lowest drawers.**

This is a permanent label. Do not remove!