











DJYC2403 / 2403B








ASSEMBLY INTRODUCTION



Plate





Fitting



1


A x 24






2

Remove the protective film of the acrylic sheet.

B x 4





3






4



Remove the protective film of the acrylic sheet.



5




6




Remove the protective film of the acrylic sheet.

7

D x 4





F x 1



8

B x 4



Remove the protective film of the acrylic sheet.


9

B x 4






10

D x 4





F x 1






Remove the protective film of the acrylic sheet.

11







12






Remove the protective film of the acrylic sheet.

13





14



15

G x 16



16

D x 4



F x 1

