

# Fire Vida

## Large Steel Chimnea

ASSEMBLY INSTRUCTIONS



















**SKU**

**333423**



## PARTS LIST

Please check parts against the list below before assembling your chimenea grill, Take a few moments to familiarize yourself with the contents. Check that all holes are clear of paint before assembly.

Item.	Parts	Pic	Qty.
A	Rain Lid		1
B	Flue Grill		1
C	Top Flue		1
D	Main Flue		1
E	Mesh Door		1
F	Top Bowl		1
G	Mesh Body		1
H	Bottom Bowl		1
I	Charcoal Grid		1
J	Leg		3
K	Leg Ring		1
L	Connection Plate		6
M	Poker		1
T1	Bolt M6X20mm		27
T2	Bolt M6X25mm		6
U	Washer		33
V	Nut		33
X	Lock Washer		33



- Dispose of all polythene packing carefully and keep out of the reach of children..
- Please read the section on chimenea safety prior to using your chimenea.

Please read all instructions carefully and keep outer packaging to refer To photograph of finished product in case of difficulty.


# ASSEMBLY



**WARNING**



- While every effort has been made in the manufacture of your chimenea to remove any sharp Edge, you should handle all components with care to avoid accidental injury.
- Tools required: Either a crosshead or flat-bladed screwdriver and either an Adjustable wrench or a pair of pliers



## STEP 1 -ATTACHING LEGS

Attach legs (J) to leg ring (K) using bolts (T1), washers(U), lock washer (X) and nuts (V).

Attach legs(J) to bottom bowl (H) using bolts (T2), washers (U), lock washers (X) and nuts (V), Tighten loosely.

## STEP 2 –ASSEMBLY GRATE

Insert charcoal grid (I) in the bottom bowl (H).

Attach connection plates (L) to bottom bowl (H) using bolts (T1) washers (U), lock washers (X) and nuts(V). Do not tighten

### **STEP 3 –ASSEMBLY MESH BODY**

Install mesh body (G) on bottom bowl (H)

Align connection plates (L) and fasten using bolts (T1) washers (U), lock washers (X) and nut (V)

Tighten all the bolts & nuts gently, do not over-tighten

### **STEP 4 –ASSEMBLY TOP BOWL**

Install top bowl (F) on mesh body (G).

Align the holes on the top with connection plate (L) on the mesh body (G) and connect using bolts (T1) washers (U), lock washers (X) and nuts (V). Tighten securely, do not over-tighten.

### **STEP 5 –ASSEMBLY FLUE**

Connect main flue (D) to top bowl (F) using bolts (T1), washers (U), lock washers (X) and nuts (V).

Connect top flue (C) to main flue (D) using bolts (T1), washers (U), lock washers (X) and nuts (V).

Place flue grill (B) and rain lid (A) onto the top flue (C), as shown.

### **STEP 6 –PLACE THE MESH DOOR**

Install the mesh door (E) onto the mesh body (G).

To move the hot parts use the poker (M).

## **INSTRUCTIONS FOR USE**

1. Make sure the assembly instructions have been followed correctly
2. Set the chimenea up in a suitable position on a level surface away from areas likely to catch fire .  
The base of the chimenea will get hot so ensure it stands on suitable surface
3. Use wood (Charcoal) and a suitable lighting method :

#### **Method 1 – charcoal & Lighting Fluid**

- a) Set up your chimenea in a safe place .Place enough charcoal in the firebowl to a depth of 3-5cm.
- b) Taking care not to spill any liquid onto your hands or clothes .Squirt the lighting fluid over the charcoal.
- c) Wait for 30 seconds to allow the liquid to soak into the charcoal.
- d) Do not light the charcoal if you have spilt fluid onto your clothes. Light the charcoal using a long taper or safety lighter .The charcoal will then burn for a period with flames
- e) Do not squirt liquid onto burning charcoal .Stand well back from the chimenea and repeat –steps b) to e).

#### **Method 2 – Lighting Blocks**

- a) Place three or four Lighting Blocks in the centre of the appliance bowl and light with a match
- b) Place pieces of wood (Charcoal) around each burning block .Add more wood (Charcoal) as required, in a pyramid formation.

#### **4. ALWAYS WEAR OVEN GLOVES WHEN HANDLING**

5. If using split or full logs ensure they are fully and treatment free (painted etc.) to avoid smoking and spitting.
6. Ensure spark guard is securely in place once lit .Always use hook provided when fitting or removing spark guard to avoid risk of burns.
7. Ensure there is at least 1 metre clearance around all sides of the chimenea , keep away from fences ,over hanging branches and other combustible materials.