



HARDWARE LIST

A(4) Allen Bolts
B(4) Spring Washers
C(4) Metal Washers
D(1) Allen Wrench

PARTS LIST

E (1) Top Section
F (1) Bottom Section
G(5) Casters

TOOLS REQUIRED FOR ASSEMBLY:
ALLEN WRENCH (INCLUDED)



*** ASSEMBLY ***

STEP 1

Attach Top Section (E) to Bottom Section (F), using 4 Allen Bolts (A), 4 Spring Washers (B) & 4 Metal Washers (C) to hold tight in place. Please tighten all bolts using Allen Wrench (D) provided to prevent stripping of wood.

STEP 2

Insert each Caster (G) into bottom of each foot on Bottom Section (F). Make sure each caster is properly inserted and lightly fit before use. Assembly of your new game chair is now complete.