

Style1. Single Led Light

Switch for Water Speed Adjustment.
(Initial status is on the max)



Package Including:
Integrated power cord:
LED light+pump+plug*1
Water Fountain*1
The Basement*1



1. Connect the pump with the hose built-in the fountain.




2. Insert the LED light into the hole of the fountain.



Step 3. Put the assembled fountain onto the basement.

Style2.LED Lights Set (with ball)



Package Including:
Integrated power cord: LED light+pump+plug*1
Water Fountain*1
The bottom*1
Crystal-like Ball*1




Step 1. Insert the hose built-in the fountain to the LED lights



Step 2. Push the LED lights to the top of the hose as much as possible.



Step 3. Connect the pump with the hose built-in the fountain



Step 4. Put the assembled fountain onto the basement, and put the ball onto the top of the fountain.

Remark: If pump stop working, unplug the fountain and remove the ball for seconds to let the air out, then plug again.