USE AND MAINTENANCE

Use on level surfaces only


Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

4.5ft Artificial Christmas Tree


PART LIST



1 - The Top Section Of The Tree ×1



2 - The Bottom Section Of The Tree ×1



3 - Stand x 1



4 - Branch × 1




5 - Leaf ×1


SAVE THESE INSTRUCTIONS



Assembly Instructions

READ AND FOLLOW ALL SAFETY INSTRUCTIONS





Congratulations! Setup of your new 4.5ft Artificial Christmas Tree is Complete!

Spread out each tips like 5.