



INSTRUCTION MANUAL



ASSEMBLY INSTRUCTIONS

Carefully unpack all the components and verify that all the necessary parts are included as listed in the packaging.

Identify each component and refer to the provided assembly diagram or step-by-step instructions.

Assemble the furniture in the order specified to ensure proper alignment and fit.

Use the provided tools or recommended tools for assembly. Do not use excessive force when tightening screws or bolts.








If any difficulties arise during assembly, consult the troubleshooting section or contact our customer support.

Tools Required











Wrench tool

Board parts List

NO.	PICTURE	QTY	NO.	PICTURE	QTY	NO.	PICTURE	QTY
1	 Panel	1	5	 Activity board	1	9	 Door	2
2	 Baseboard	1	6	 Later strengthened strips	1	10	 Handle	2
3	 Left side panel	1	7	 Upper back panel	1	11	 Foot	4
4	 Right side plate	1	8	 lower back panel	1			

Hardware parts List


NO.	PICTURE	QTY	NO.	PICTURE	QTY	NO.	PICTURE	QTY
A	 Ø6x35mm Bolt	4	G	 Iron layer support	4	M	 Ø3x16mm Screw	8
B	 Ø15x9.5mm Bolt	4	H	 Hinge	4	N	 Adjustable foot nail	4
C	 Ø8x30mm Wood Dowel	8	I	 Wrench	1	O	 Ø4x30mm Screw	4
D	 Ø4x35mm Screw	2	J	 Prevent falling	2	P	 Plastic swells	2
E	 Ø4x14mm Screw	24	K	 Ø4x14mm Screw	2			
F	 Ø7x40mm Screw	4	L	 Back panel buckle	8			



ASSEMBLY INSTRUCTIONS


STEP 1

	
A	X4
	
J	X2
	
K	X2





STEP 2


	
A	X4



STEP 3







STEP 4




ASSEMBLY INSTRUCTIONS



STEP 5




STEP 6



STEP 7






STEP 8






ASSEMBLY INSTRUCTIONS



STEP 9




STEP 10



STEP 11






STEP 12






ASSEMBLY INSTRUCTIONS

STEP 13










STEP 14



STEP 15

Pre-drilled hole at wall





MAINTENANCE AND CARE

Clean regularly using a soft brush or vacuum with a brush attachment. Avoid harsh chemicals or abrasive cleaners.

Wash with a hose or pressure washer on a low-pressure setting for heavy soiling. Rinse thoroughly afterward.

Ensure proper drying after cleaning or exposure to rain to prevent mold or mildew growth.

Protect from extreme weather by moving furniture to a covered area or using furniture covers or tarps.

Avoid dragging or placing heavy objects on the furniture to prevent damage.

Apply UV protection spray or furniture wax to prevent fading and damage from the sun.

Regularly inspect for wear, loose strands, or damage and address issues promptly.



WARRANTY INFORMATION

Warranty Coverage: Our warranty provides protection against manufacturing defects in materials and workmanship for a specified period from the date of purchase, as outlined in the accompanying warranty documentation.

Exclusions: The warranty does not cover damages resulting from misuse, negligence, accidents, normal wear and tear, unauthorized repairs or modifications, improper assembly, or failure to adhere to the care and maintenance guidelines provided.

Warranty Claim Process

To initiate a return, please follow these steps:

- 1 Log into your account and go to the "Your Orders" section.
- 2 Locate the order containing the item you wish to return.
- 3 Contact our customer service for assistance in obtaining a prepaid return label.
- 4 Once you receive the return label, securely affix it to the package.
- 5 You can then choose to drop off the package at a designated carrier location or arrange for a pickup.
- 6 After we receive and inspect the returned product, we will initiate the refund process.
- 7 The refund will be credited back to the original payment method used during the purchase.
- 8 Typically, refunds are processed within 3-5 business days.