


INSTRUCTION

PATIO WICKER 2PCS SWIVEL CHAIR



After-sales mailbox:
Patiofurniture Serviceteam@outlook.com

NOTICE

EN

Please keep these instructions for future reference.

Dear Customer

● Thank you for your purchase. When you receive the product, please make sure that all the parts are intact. If any parts are missing, please contact us promptly to request replacement parts.

● Then follow the entire installation instructions to install.

● Each part is crucial, so please be careful not to lose any. It is recommended to store parts with different lettered identifiers in separate boxes or bags to avoid confusion during installation.

A . The outer box is damaged

B . The product is damaged / bent / cracked while you open the box

C . The parts / accessories / assembly tools are missing

D . The instructions are not clear and can not be referred

E . The product has functional problems

F . Other aspects that you are not satisfied with

Please feel free to contact us for help, and provide the following information:











Platform/Shop name/Order id/Buyer's name/Receiver's address/Problem description/Problem pictures







(Patiofurniture Serviceteam@outlook.com) will reply within 24 hours and will do our best to resolve the problem for you.

Note: First tighten each screw by 60%, and then tighten it according to each part.



PART LIST

A  x 2	B  x 2	C1  x 2	D  x 2
E  x 2	F  x 4	G  x 2	I  x 2
J  x 2	R  x 2	S  x 2	Z  x 4


1  M6*55MM x 8	2  M6*35MM x 44	3  M6*20MM x 8	4  M6 x 76
5  M6 x 24	6  x 12	8  TOOL x 1	9  TOOL x 1

STEP

01

Tighten screws to 60% first.

Note: The red circle holes on the way are designed to make the components universal. No assembly screws are required for these holes.



2



M6*35MM
5PCS


4



M6
5PCS

02

Tighten screws to 60% first.



2



M6*35MM
4PCS



4



M6
4PCS

03

Tighten screws to 60% first.



2



M6*35MM
5PCS

4





M6
5PCS

04

Tighten screws to 60% first.

PAET F, please note that the installation should be from top to bottom, from high to low.



3



M6*20MM
4PCS


4



M6
4PCS

05

Tighten screws to 60% first.




1
M6*55MM
4PCS

4
M6
8PCS

5
M6
4PCS

06

Tighten screws to 60% first.



2
M6*35MM
4PCS

4
M6
4PCS

5
M6
4PCS

07

Tighten all screws to 100%.

2

M6*35MM
4PCS

4

M6
8PCS

5

M6
4PCS

6

6PCS

08

R

1PC

S

1PC

Z

2PCS

05

AFTER-SALE SERVICE

If you have any suggestions for our products or notice any quality issues, please contact us first. Our after-sales team will respond within 24 hours and will do everything possible to provide you with a satisfactory solution.

Guaranteed Customer Service

Your shopping experience is very important to us!

Feel unsatisfied? **Contact us!**

Have any questions? **Contact us!**

Wanna Share how wonderful our smart products make your home?

Share your pictures with us.

Any suggestions? **Contact us!**


We will check and give feedback.



Patiofurnitureserviceteam@outlook.com



PATIO WICKER 3-SEAT COUCH



After-sales mailbox:
Patiofurniture Serviceteam@outlook.com

NOTICE

EN

Please keep these instructions for future reference.

Dear Customer

● Thank you for your purchase. When you receive the product, please make sure that all the parts are intact. If any parts are missing, please contact us promptly to request replacement parts.

● Then follow the entire installation instructions to install.

● Each part is crucial, so please be careful not to lose any. It is recommended to store parts with different lettered identifiers in separate boxes or bags to avoid confusion during installation.

A . The outer box is damaged

B . The product is damaged / bent / cracked while you open the box

C . The parts / accessories / assembly tools are missing

D . The instructions are not clear and can not be referred

E . The product has functional problems

F . Other aspects that you are not satisfied with

Please feel free to contact us for help, and provide the following information:










Platform/Shop name/Order id/Buyer's name/Receiver's address/Problem description/Problem pictures





(Patiofurniture Serviceteam@outlook.com) will reply within 24 hours and will do our best to resolve the problem for you.

Note: First tighten each screw by 60%, and then tighten it according to each part.



PART LIST

A  x 1	B  x 1	C  x 3	D  x 3
E  x 3	K  x 8	L  x 2	R  x 3
S  x 3	Z  x 2		


1  M6*55MM x 14	2  M6*35MM x 22	4  M6 x 50	5  M6 x 14
7  M6*120MM x 8	8  TOOL x 1	9  TOOL x 1	

STEP

01

Tighten screws to 60% first.

Note: The red circle holes on the way are designed to make the components universal. No assembly screws are required for these holes.



2



M6*35MM
5PCS


4



M6
5PCS

02

Tighten screws to 60% first.



2



M6*35MM
4PCS

4




M6
4PCS

03

Tighten all screws to 100%.

7




M6*120MM
4PCS


K



4PCS



04 Tighten screws to 60% first.



- 1 M6*55MM 2PCS
- 2 M6*35MM 2PCS
- 4 M6 6PCS
- 5 M6 2PCS

05

Tighten screws to 60% first.

1


 M6*55MM
 2PCS

4

 M6
 4PCS


5

 M6
 2PCS



06

Tighten screws to 60% first.






1	
	M6*55MM 3PCS
2	
	M6*35MM 2PCS
4	
	M6 8PCS
5	
	M6 3PCS

STEP


07

Tighten all screws to 100%.



08

Tighten screws to 60% first.



1	
	M6*55MM 2PCS
2	
	M6*35MM 2PCS
4	
	M6 6PCS
5	
	M6 2PCS

09

Tighten screws to 60% first.

Diagram illustrating the assembly of a metal frame. The frame consists of vertical posts and horizontal rails. A red rectangular panel, labeled 'C', is being attached to the top of the frame. A side panel, labeled 'E', is also visible. Two circular callouts show the assembly of a screw (1), washer (4), and nut (5) into the frame. The callouts are labeled with 1, 4, and 5.

1

M6*55MM
2PCS

4

M6
4PCS


5

M6
2PCS


09

10

Tighten screws to 60% first.




1	
	M6*55MM 3PCS
2	
	M6*35MM 2PCS
4	
	M6 8PCS
5	
	M6 3PCS



11

Tighten all screws to 100%.



2




M6*35MM
5PCS

4



M6
5PCS

7




M6*120MM
2PCS

K



2PCS



AFTER-SALE SERVICE

If you have any suggestions for our products or notice any quality issues, please contact us first. Our after-sales team will respond within 24 hours and will do everything possible to provide you with a satisfactory solution.

Guaranteed Customer Service

Your shopping experience is very important to us!

Feel unsatisfied? **Contact us!**

Have any questions? **Contact us!**

Wanna Share how wonderful our smart products make your home?

Share your pictures with us.

Any suggestions? **Contact us!**


We will check and give feedback.



Patiofurnitureserviceteam@outlook.com



PATIO WICKER 2PCS OTTOMAN



After-sales mailbox:
Patiofurniture Serviceteam@outlook.com

NOTICE

EN

Please keep these instructions for future reference.

Dear Customer

● Thank you for your purchase. When you receive the product, please make sure that all the parts are intact. If any parts are missing, please contact us promptly to request replacement parts.

● Then follow the entire installation instructions to install.

● Each part is crucial, so please be careful not to lose any. It is recommended to store parts with different lettered identifiers in separate boxes or bags to avoid confusion during installation.

A . The outer box is damaged

B . The product is damaged / bent / cracked while you open the box

C . The parts / accessories / assembly tools are missing

D . The instructions are not clear and can not be referred

E . The product has functional problems

F . Other aspects that you are not satisfied with

Please feel free to contact us for help, and provide the following information:





Platform/Shop name/Order id/Buyer's name/Receiver's address/Problem description/Problem pictures





(Patiofurniture Serviceteam@outlook.com) will reply within 24 hours and will do our best to resolve the problem for you.

Note: First tighten each screw by 60%, and then tighten it according to each part.



PART LIST


K  x 8	M  x 8	N  x 2	O  x 2
--	--	---	--

2  M6*35MM x 24	4  M6 x 24	7  M6*120MM x 8	8  TOOL x 1
--	---	---	--

STEP

01

Tighten screws to 60% first.



2



M6*35MM
4PCS


4



M6
4PCS

02

Tighten screws to 60% first.



2



M6*35MM
3PCS


4



M6
3PCS

03

Tighten screws to 60% first.



2



M6*35MM
5PCS


4




M6
5PCS

04

Tighten all screws to 100%.



7





M6*120MM
4PCS

K



4PCS

05



AFTER-SALE SERVICE

If you have any suggestions for our products or notice any quality issues, please contact us first. Our after-sales team will respond within 24 hours and will do everything possible to provide you with a satisfactory solution.

Guaranteed Customer Service

Your shopping experience is very important to us!

Feel unsatisfied? **Contact us!**

Have any questions? **Contact us!**

Wanna Share how wonderful our smart products make your home?

Share your pictures with us.

Any suggestions? **Contact us!**

We will check and give feedback.



Patiofurniture Serviceteam@outlook.com

