LED Birch Tree Instruction

31.5”

4.7”

7.5”

WEIGHT: 6.6 LB

1. Take out product from package;

2. Insert tree trunk into base and rotate until fixed. Insert tree top into trunk.

3. Fix base with ground stakes(when using outdoor); Connect the cable with transformer.



The tree can be shaped by bending and arranging the branches into desired position to give it a natural appearance!