
MANUAL INSTRUCTION

TV STAND





- The product must be assembled and used in accordance with the provisions of the manual. The seller does not assume any responsibility or liability with respect to any damage caused by incorrect assembly or improper use.
- 2. Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- 3. Please read assembly instructions before start.
- 4. Please remember: This summary may not include every detail of all variations or considered steps.
- 5. Please contact us when further information are needed.

Warnings

- 1. It is strictly prohibited to sit or stand on the product.
- 2. Please put this item on a flat ground.
- During the assembly process, keep any small parts out of the reach of children. It may be fatal if swallowed or inhaled
- 4. To avoid the potential dangers of suffocation, please keep all parts and packaging (films, plastic bags and foam, etc.) away from babies and children.
- 5. If there is/are defective and/or missing part(s) after unpacking, please cease assembly immediately and get in contact with us as soon as possible.

Tools Required









If electric tools are required, please reduce the torque to prevent product damage during installation.

PARTS







Up to 30 Minutes For Assembly



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size.



PARTS



HARDWARE



Ф8х30mm **А х 11**



Φ15x12mm

(B) × 36 (+1)




© × 36 (+1)





E × 8 (+1)




M4x18mm **F** × 2





(G) × 12

I EXPLOSION DIAGRAM


















A X 3












Turn over the part assembled in step 2, and then install the 4 Cs into the corresponding holes on plate ②.
































(A) X 2




















10

















































After installing component D, tear off the film on the front of the door panel. If there are any traces left, just wipe them with a wet towel after the cabinet is installed.

The door panel has a red label "Please peel off the film for highlighted surface"













Door adjustment diagram:













For aesthetics, you can use G to paste the exposed hardware holes according to your needs.



Remove four silver screws from the sides of the heaterm, two screws on each side.


Remove the tempered glass by lifting ie from the lugs on the side.

put the appliance to the TV Stand by two persons.




Fix the appliance to the TV stand with 4 screws according to the hole position.

Place the front glass surround over the front of the fire aligning the slot in the bracket at each side of the glass pandel with the lugs on the sides of the fire .




- 1. Put the light strip wire through the hole(one long wire and one short wire).
- 2. Put the long one the side farther from the fireplace wire, the short one on the side closer it the fireplace wire.





Tear off the double-sided tape of the light strip and stick it on the board.



Hold the light strip with the clip and lock the screw.